


Chevrolet Camaro 1988 – 1992 fuse box diagrams

Fuse Box diagram



Chevrolet Camaro – fuse box diagram

No.	A	Circuit Protected
1	10	Engine Control Module
2	10	Fuel Injector Feed No. 1
	20	'88-'89 (Camaro): Engine Cooling Fan
	10	'88-'89 (Firebird): Fuel Pump, Oil Pressure Switch, Electric Cluster
3	15	'90-'92: Hatch Pull-Down Motor
	3	'88-'89: Crank Signal to E.C.M.
4	20	Cooling Fan Relay
5	20	Turn Signal Lights, Back-Up Lights
6	10	'90-'92: Fuel Injector Feed No. 2
	10	'88-'89 (Camaro): Fuel Injector
	20	'88-'89 (Firebird): Fuel Injector
7	20	Parking Lights, Side Marker Lights, Taillights
8	25	Heater or Air Conditioner
9	10	Gauges, Audio Alarm System, Vehicle Speed Sensor, TCC Brake Switch, Rear Window Defogger, Daytime Running Lights, Cruise Control, A/C Relay
10	10	'90-'92: Supplemental Inflatable Restraint
	10	'88-'89 (Camaro): Fuel Pump, Fuel Injector
	20	'88-'89 (Firebird): Fuel Injector
11	20	Glove Box Light, Cigarette Lighter, Hatchback Lid Release, Horn Relay, Interior Lights, Power Antenna, Power Door Locks, Radio/Digital Clock, Computer Command Control
13	5	Instrument Panel Lights

14	10	Radio
16	25	Windshield Wiper/Washer
17	20	Stoplight Switch, Hazard Flasher, Chime
18	10	'90-'92: VATS II Security Light
19	20	'90-'92: Radio
20	3	'90-'92: ECM Crank Circuit
21	10	'90-'92: Daytime Running Lights
Circuit Breaker		
12	35	'88-'90: Power Windows, Rear Wiper/Washer
	30	'91-'92: Power Windows
15	35	'88-'90: Power Door Locks, Power Seats, Rear Window Defogger
	30	'91-'92: Power Door Locks, Power Seats, Rear Window Defogger
22	30	'90-'92: Fog Light