



D RELAY LOCATIONS


[Engine Compartment]




② : R/B No. 2 Front Side of Left Fender




[Body]




(Tail Gate Type)



(Swing Out Type)




[RHD: Instrument Panel]



24

LHD: Left Kick Panel (See Page 24)

RHD: Right Kick Panel (See Page 24)



Fuse Block

LHD: Instrument Panel Left (See Page 24)

RHD: Instrument Panel Right (See Page 24)

