


Alfa Romeo Giulietta 2010 – 2013 fuse box diagram


Fuse box in engine compartment



Alfa Romeo Giulietta – fuse box – engine


compartment

Fuse box in dashboard



Alfa Romeo Giulietta – fuse box – dashboard

Fuse box in the boot



Alfa Romeo Giulietta – fuse box – boot

Fuse table

Light	Fuse	Ampere rating [A]	Location
Right main beam headlight	F91	7,5	Dashboa rd
Left main beam headlight	F90	7,5	Dashboa rd
Right dipped beam headlight (versions with halogen headlights)	F12	7,5	Dashboa rd
Left dipped beam headlight (versions with halogen headlights)	F13	7,5	Dashboa rd
Right dipped beam headlight (versions with Bi-Xenon headlights)	F12	15	Dashboa rd
Left dipped beam headlight (versions with Bi-Xenon headlights)	F13	15	Dashboa rd
Right fog light	F93	7,5	Dashboa rd
Left fog light	F92	7,5	Dashboa rd

Boot light/Sun visor lights/ Door puddle light/Glove compartment light/ Front/rear ceiling light Radionavigator display	F32	10	Dashboard
--	-----	----	-----------

Users	Fuse	Ampere rating [A]	Location
Headlight washer pump supply	F09	30	Engine compartment
Horn	F10	15	Engine compartment
AC compressor	F19	7,5	Engine compartment
Heated rear window	F20	30	Engine compartment
Fuel pump	f21	15	Engine compartment
Fuel pump	F21	20	Engine compartment
Various devices	F31	5	Dashboard
Rear electric window (left side)	F33	20	Dashboard
Rear electric window (right side)	F34	20	Dashboard
+30	F36	10	Dashboard
Various devices	f37	7,5	Dashboard
Central locking	F38	20	Dashboard

Body Computer power supply	F42	5	Dashboard
Two-way windscreen washer pump	F43	20	Dashboard
Front electric window (driver side)	F47	20	Dashboard
Front electric window (passenger side)	F48	20	Dashboard
Various devices	F49	5	Dashboard
Various devices	F51	5	Dashboard
+30	F53	7,5	Dashboard
Lumbar adjustments	F60	15	Boot
Front seat heater	F61	15	Boot
BOSE amplifier + Subwoofer	F62	20	Boot
Left front seat movement	F63	15	Boot
Right front seat movement	F64	15	Boot
Electric sunroof	F65	15	Boot
Cigar lighter/power socket	F85	15	Boot
12V boot power socket	F86	15	Boot

IBS Battery charge status sensor for Start&Stop system	F87	5	Boot
External mirror defrosters	F88	7,5	Boot