




[Body]




[Engine Compartment] (LHD)




[Engine Compartment] (RHD)






[R/B Assembly No. 2 Inner Circuit]




(Cont. Next Page)

[R/B Assembly No. 2 Inner Circuit]




① : Engine Room R/B No. 1	Front Fender Apron LH
○ : Engine Room J/B No. 1	



① : Engine Room R/B No. 1	Front Fender Apron LH
○ : Engine Room J/B No. 1	

Unit A



cardiagn.com


① : Engine Room R/B No. 1

○ : Engine Room J/B No. 1

Front Fender Apron LH


Unit B

- * 1:50A DEF
- * 2:40A HTR
- * 3:30A ABS MTR NO.2
- * 4:30A FAN NO.2
- * 5:30A FAN NO.1
- * 6:30A ABS-MAIN
- * 7:30A PTC HTR NO.3
- * 8:30A PTC HTR NO.2
- * 9:50A PTC HTR NO.1




① : Engine Room R/B No. 1	Front Fender Apron LH
○ : Engine Room J/B No. 1	

Unit C




① : Engine Room R/B No. 1	Front Fender Apron LH
○ : Engine Room J/B No. 1	


Unit D



[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]




[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]




cardiagn.com


[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]





[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]




[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]




Fusible Link Block Assembly	Front Fender Apron LH
------------------------------------	------------------------------




[Fusible Link Block Assembly Inner Circuit]




- * 1:30A POWER
- * 2:30A P/SEAT
- * 3:30A S/ROOF




View A




View B



View C




[Instrument Panel J/B Assembly Inner Circuit]



(Cont. Next Page)

[Instrument Panel J/B Assembly Inner Circuit]


(Cont'd)



(Cont. Next Page)

[Instrument Panel J/B Assembly Inner Circuit]


(Cont'd)



(Cont. Next Page)

[Instrument Panel J/B Assembly Inner Circuit]


(Cont'd)




(Cont. Next Page)

[Instrument Panel J/B Assembly Inner Circuit]

(Cont'd)





[Instrument Panel] (LHD)




[Instrument Panel] (RHD)


* 1: Refer to the Service Bulletin
for the installation position of the parts.







[R/B Assembly No. 4 Inner Circuit]



[Seat]

