


Fiat Uno fuse box diagrams

Year of production:

Fuse box




Fiat Uno – fuse box diagram

No.	A	Circuit protected
1	7.5	Left front parking, right rear tail lamp, cigar lighter illumination, heater control and clock, digital clock illumination
2	7.5	Right front parking lamp and left rear tail lamp, instrument panel illumination and rear number plate lamp
3	10	Left-hand headlamp (main beam)
4	10	Right-hand headlamp (main beam)
5	25	Engine cooling fan and horn (Comfort)
6	10	Courtesy lamps, cigar lighter , radio power feed, disc pad sensors, economy gauge (ES models)
7	10	Left-hand dipped headlamp, rear foglamps
8	10	Right-hand dipped headlamp
9	20	Heated tailgate glass
10	10	Stop lamps, direction indicator lamps, instrument panel warning lamps, tachometer economy gauge, check control system
11	20	Heater booster fan, digital clock map reading lamp
12	20	Windscreen wiper and washer, rear screen wiper/washer, check system panel illumination
13	10	Front fog lights
14	20	Spare (Comfort), Horn (Super)

15	10	Hazard warning lamps
16	–	Spare
17	–	Spare
18	–	Spare
19	–	Spare
Supplementary fuses at side of main fuse block		
Fuses (903, 999, 1116, 1299/1301 and 1301 cc Turbo ie)		
A	20	Front fog lamps
B	30	Cooling fan (Turbo ie models)
C	10	Fuel injector cooling fan (Turbo ie models)
D	30	Electric windows
E	10	Fuel pump (Turbo ie models)
Fuses (later 903, 999, 1108, 1372 ie and 1372 cc Turbo ie)		
A	30	Electric windows
B	25	Central locking (where fitted)
C	10	Injector cooling fan (where fitted)
D	20	Headlamp washers (where fitted)
E	20	Foglamp and warning lamp
F	–	Spare
G	10	Fuel pump (fuel injection models)
–	10	Heated Lambda sensor
Supplementary fuses on steering column relay bracket		
–	10	Antiskid monitor circuit (where fitted)
–	25	Antiskid supply circuit (where fitted)

Auxiliary fuses and relays on 1301 cc Turbo ie models



Fiat Uno – fuse box diagram – auxiliary fuse and relay

No.	Circuit protected
1	Horn relay
2	Heated rear screen relay
3	Foglamps relay
4	Radiator fan relay
5	Electric windows relay



Fiat Uno – fuse box diagram – auxiliary fuse



Fiat Uno – fuse box diagram – auxiliary fuse