

Dodge Caliber 2009 fuse box diagram

Integrated power module (IPM)

Cavity	Cartridge fuse	Mini fuse	Description
1	—	—	—
2	—	15	AWD/4WD ECU Feed
3	—	10	CHMSL Brake Switch Feed
4	—	10	Ignition Switch Feed/OCM
5	—	20	Trailer Tow
6	—	10	IOD Sw/Pwr Mir/Steering Cntrl Sdar/Hands-Free Phone
7	—	30	IOD Sense1
8	—	30	IOD Sense2
9	40	—	Power Seats
10	—	20	CCN Power Locks/Interior Lighting
11	—	15	Power Outlet
12	—	20	Ign Run/Acc Inverter

13	—	20	Pwr Run/Acc Outlet RR/Dome Lamp/Cigar Lighter
14	—	10	IOD CCM
15	40	—	RAD Fan Relay Battery Feed
16	—	15	IGN Run/Acc Dome Lamp/Sunroof/Rear Wiper Motor/ACC Inverter
17	—	10	IOD Feed Mod-Wcm
18	40	—	ASD Relay Contact PWR Feed
19	—	20	PWR Amp 1 & Amp 2 Feed
20	—	15	IOD Feed Radio
21	—	10	IOD Feed Intrus Mod/Siren (If Equipped)
22	—	10	IGN RUN Heat/AC/Compass Sensor
23	—	15	ENG ASD Relay Feed 3
24	—	15	Power Sunroof Feed
25	—	10	Heated Mirror (If Equipped)
26	—	15	ENG ASD Relay Feed 2
27	—	10	IGN RUN Only ORC Feed

28	—	10	IGN RUN ORC/OCM Feed
29	—	—	Hot Car (No Fuse Required)
30	—	20	Heated Seat (If Equipped)
31	—	10	Headlamp Washer Relay Control
32	30	—	ENG ASD Control Feed 1
33	—	10	ABS MOD/J1962 Conn/PCM
34	30	—	ABS Valve Feed
35	40	—	ABS Pump Feed
36	30	—	Headlamp/Washer Control/Smart Glass (If Equipped)
37	—	25	Diesel Fuel Heater — If Equipped