


Citroën Nemo (2008 – 2009) – fuse box diagram

Year of production: 2007, 2008

Dashboard fuse box




Citroen Nemo – fuse box diagram – dashboard

Fuses	A	Protected component
F12	7.5 A	Right-hand dipped headlamp supply
F13	7.5 A	Left-hand dipped headlamp supply – headlamp height adjuster
F31	5 A	Engine control unit supply switch
F32	7.5 A	Front light – front courtesy light – rear courtesy light lamp
F36	10 A	Audio equipment – mobile telephone pre-equipment – air conditioning control panel – EODB diag socket
F37	5 A	Brake light – instrument panel
F38	20 A	Locking of the doors
F43	15 A	Wipers pump
F47	20 A	Driver's electric window motor supply
F48	20 A	Passenger's electric window motor supply
F49	5 A	Parking assistance control unit – rear lighting switch – electric exterior mirrors
F50	7.5 A	Air bags control unit
F51	5 A	Switch on brake pedal – switch on clutch pedal

F53	5 A	Instrument panel – rear fog lamps
-----	-----	-----------------------------------

Engine compartment fuse box



Citroen Nemo – fuse box diagram – engine

compartment

Fuses	A	Protected component
F01	60 A	Control unit
F03	20 A	Starter supply
F04	40 A	ABS hydraulic block pump supply
F06	30 A	Single speed fan assembly control
F07	40 A	High speed fan assembly control
F08	30 A	Air conditioning unit pump
F10	10 A	Horn
F11	10 A	Engine management secondary charge supply
F14	15 A	Main beam headlamps
F16	7.5 A	Engine management control unit – electronic gearbox system control unit
F17	15 A	Supply for ignition coil, injectors, engine management central unit
F18	7.5 A	Engine management control unit (1.4 HDi)
F19	7.5 A	Air conditioning compressor
F20	30 A	Supply for heated rear screen, electric exterior mirrors de-icing heaters
F21	15 A	Engine management 1.4 petrol, relay coil T09 (HDi)

F22	20 A	Engine management control unit (1.4 HDi), petrol pump
F23	20 A	ABS hydraulic block solenoid valves supply
F24	7.5 A	ABS
F30	15 A	Fog lamps
F81	60 A	Pre-heat unit
F82	30 A	Electronic gearbox system pump – electronic gearbox system supply
F84	10 A	Electronic gearbox system control unit and valves
F85	30 A	Lighter -12 V accessories socket
F87	7.5 A	Reversing lights – water in diesel sensor

WARNING: Terminal and harness assignments for individual connectors will vary depending on vehicle equipment level, model, and market.