



- LK** : МОДЕЛЬ С ЛЕВОСТОРОННИМ УПРАВЛЕНИЕМ С СИСТЕМОЙ ЗАПУСКА/ОСТАНОВКИ ДВИГАТЕЛЯ ПРИ ПОМОЩИ КНОПКИ
- LE** : КРОМЕ МОДЕЛИ С ЛЕВОСТОРОННИМ УПРАВЛЕНИЕМ С СИСТЕМОЙ ЗАПУСКА/ОСТАНОВКИ ДВИГАТЕЛЯ ПРИ ПОМОЩИ КНОПКИ
- \*1** : ПРОИЗВОЛЬНЫЕ НОМЕРА КЛЕММ ИЗ 1, 2, 5 И 6
- \*2** : ПРОИЗВОЛЬНЫЕ НОМЕРА КЛЕММ



(B220)

|   |   |    |    |    |    |
|---|---|----|----|----|----|
| 1 | 2 | 9  | 13 | 17 | 21 |
| 3 | 4 | 10 | 14 | 18 | 22 |
| 5 | 6 | 11 | 15 | 19 | 23 |
| 7 | 8 | 25 | 29 | 33 | 37 |
|   |   | 26 | 30 | 34 | 38 |
|   |   | 27 | 31 | 35 | 39 |
|   |   |    | 32 | 36 | 40 |

(B3)

|   |   |   |   |   |
|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 |
|---|---|---|---|---|

A: (B134)

|   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |
|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 |
| 3 | 4 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |
| 5 | 6 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 |
|   |   | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 |

(B83) (B122)

|   |   |   |   |
|---|---|---|---|
| 1 | 2 | 3 | 4 |
| 5 | 6 | 7 | 8 |

B: (B135)

|    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |
| 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 |
| 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 |
| 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 |