


ЭЛЕКТРОМАГНИТНЫЙ КЛАПАН
УПРАВЛЕНИЯ ПОТОКОМ МАСЛА
ЛЕВОГО ВПУСКНОГО
РАСПРЕДЕЛИТЕЛЬНОГО ВАЛА

B137

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17				
18	19	20	21	22	23	24
25	26	27		28	29	30
						31

B21



E37

