

К ЦЕПИ
ЭЛЕКТРОПИТАНИЯ
FB-3
ПРЕДОХРАНИТЕЛЬ
F/V №8 (B)

WL

ПРЕДОХРАНИТЕЛЬ
(БЛОК РЕЛЕ)
7,5 A

BrR 33

32 Lg

B225

B65

ВЫКЛЮЧАТЕЛЬ СТОП-СИГНАЛОВ
И ДАТЧИК НАЖАТИЯ ПЕДАЛИ ТОРМОЗА

WL 2

3 BrW

BrW F9

БЛОК
ПРЕДОХРАНИ-
ТЕЛЕЙ
И РЕЛЕ (F/V)

F5 BrR

Br

B: R168

F: B159

Lg A40

ЕСМ

A: B134

ЦЕНТРАЛЬНЫЙ БЛОК
УПРАВЛЕНИЯ

Lg B2

B: B280

B434

B439

Lg 4

Lg 5

Lg 30

БЛОК УПРАВЛЕНИЯ
СИСТЕМОЙ VDC

B310

РАЗЪЕМ ПРИЦЕПА

3 Br

8 BY

7 BY

R79

3

8

7

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

BY

СМ. ЦЕПЬ МАССЫ
[GND(RD)-04 • 05]

СМ. ЦЕПЬ МАССЫ
[GND(RD)-05]

ЛЕВЫЙ ЗАДНИЙ
КОМБИНИРОВАННЫЙ
ФОНАРЬ




R28

ПРАВЫЙ ЗАДНИЙ
КОМБИНИРОВАННЫЙ
ФОНАРЬ


R26

ВЕРХНИЙ
СТОП-СИГНАЛ


D39




B225 (ЧЕРНЫЙ)




B: R168




B: B280 (ТЕМНО-СЕРый)



B310 (ЧЕРНЫЙ)



A: B134 (ЧЕРНЫЙ)



БЛОК РЕЛЕ