

Chrysler Voyager 2001 – 2007 fuse box diagram

Fuse box diagram



Chrysler Voyager – fuse box diagram

No	A	Circuit Protected
.		
1	20	Front Fog Lamp Relay, Front Control Module
2	15	<i>except Export:</i> Left Front Park/Turn Signal Lamp, License Lamp, Trailer Tow Connector, Left Rear Lamp Assembly, Front Control Module
	15	<i>Export:</i> Left Park Lamp, Left Headlamp Leveling Motor, License Lamp, Left Rear Lamp Assembly, Front Control Module
3	15	<i>except Export:</i> Right Rear Lamp Assembly, Right Front Park/Turn Signal Lamp (except Export), Front Control Module
	15	<i>Export:</i> Right Park Lamp, Right Headlamp Leveling Motor, Headlamp Switch, Right Rear Lamp Assembly, Front Control Module
4	30	Front Wiper On/Off Relay (Front Wiper High/Low Relay, Wiper Module), Front Control Module
5	20	Front Cigar Lighter, Radio

6	2 0	Rear Power Outlet, Flor Console Lamp, Flor Console Power Outlet
8	2 0	Horn Relay
9	4 0	Starter Relay, ABS, Front Control Module, Front Blower Motor Relay, Rear Blower Motor Relay, Defogger Relay, Fuse: "14", "15"
	3 0	'01: Starter Relay, ABS
10	4 0	Front Blower Resistor (Manual A/C), Front Blower Module (Automatic A/C)
11	2 0	Sunroof Module, Rear Wiper Motor, Radio, Amplifier
12	2 5	Rear A/C Heater Unit (Manual A/C), Rear Blower Motor Power Module (Automatic A/C)
13	4 0	Rear Window Defogger Relay
14	2 0	Radio, Front Control Module, Speaker Relay, Body Control Module, Auto Temperature Control, Sentry Key Remote Entry Module, Overhead Console, Adjustable Pedals Switch (except Export), DVD/CD Changer, Thatcham Alarm Module (UK), Siren (UK)
	1 5	'01: Radio, Speaker Relay, Front Control Module, Body Control Module, Overhead Console, Sentry Key Immobilizer Module, Auto Temperature Control, Sentry Key Remote Entry Module
15	2 0	<i>Gasoline:</i> Transmission Control Relay (Transmission Solenoid/Pressure Switch Assembly, Powertrain Control Module)
	2 0	<i>Diesel:</i> Lift Pump Relay, Cabin Heater Assist
16	2 5	<i>Gasoline:</i> Auto Shut Down Relay (Powertrain Control Module, Ignition Coil, Fuel Injector)
	2 5	<i>Diesel:</i> ECM/PCM Relay (Engine Control Module, Generator, Mass Air Flow Sensor, Fuel Pressure Solenoid, Glow Plu Relay, Camshft Position Sensor, EGR Solenoid, Air Conditioner Compressor Clutch, Radiator Fan

		Relay: No.1, No.2, No.3)
17	2 0	<i>Gasoline:</i> Powertrain Control Module, Fuel Pump Relay
	2 0	<i>Diesel:</i> Fuel Heater Relay (Crank Case Ventilation Heater, Fuel Heater)
18	1 5	Air Conditioner Compressor Clutch Relay, Power Mirror Switch, Adjustable Pedals Relay (except Export), Passenger Folding Mirror Relay (Export), Ignition Switch (Export), Thatcham Alarm Module (UK), Sentry Key Remote Entry Module (Export)
	2 0	'01: Air Conditioner Compressor Clutch Relay, Passenger Folding Mirror Relay (Export), Power Mirror Switch
19	4 0	Body Control Module
20	4 0	Body Control Module
	3 0	Amplifier
21	2 5	ABS
22	4 0	Power Seat Circuit Breaker (Driver/Passenger Power Seat Switch, Driver/Passenger Heated Seat Module, Memory Seat/Mirror Module)
23	1 0	Ignition Switch (Sentry Key Remote Entry Module, Park Assist Module, Thatcham Alarm Module (UK))
24	2 0	Body Control Module, Instrument Cluster, Message Center (Highline), Left/Right Repeater Lamp (Export)
26	2 0	Stop Lamp Switch
27	4 0	<i>Gasoline:</i> Radiator Fan Relay

	4 0	<i>Diesel:</i> Radiator Fan Relay No.2
28	4 0	Power Window Circuit Breaker
30	4 0	Headlamp Washer Relay (Export), Front Control Module
31	4 0	Dual Power Sliding Door, Right Power Sliding Door, Left Power Sliding Door
32	4 0	Sunroof Module (except Export), Power Liftgate Module
33	1 5	Front Washer Pump Motor, Rear Washer Pump Motor
PTC Fuse		
4	8	Left/Right Power Mirror
7	1 3	Power Outlet, Floor Console Power Outlet, Data Link Connector
Relay		
R1	–	
R2	Headlamp Washer (Export)	
R3	Park Lamp	
R4	Horn	
R5	Front Fog Lamp	

R6	Air Conditioner Compressor Clutch
R7	<i>Gasoline:</i> Fuel Pump
	<i>Diesel:</i> Fuel Heater
R8	Rear Window Defogger
R9	Rear Blower Motor
R10	Front Blower Motor
R11	Accessory
R12	Starter
R13	<i>Gasoline:</i> Auto Shut Down
	<i>Diesel:</i> ECM/PCM
R14	Front Wiper High/Low
R15	Front Wiper On/Off
R16	<i>Gasoline:</i> Transmission Control
	<i>Diesel:</i> Lift Pump
R17	Speaker