






G37(A), G38(B), G40(C),
G41(D), a2(E), d1(I), d3(J)
Radio & Display Receiver Assembly
G113(K), G114(L), G115(M),
G116(N), a3(O)
Navigation Receiver Assembly
G117(F), G118(G), G119(H)
Radio Receiver Assembly




- * 3 : 6 Speaker
- * 4 : 4 Speaker
- * 5 : 2 Speaker
- * 6 : Double Cab
- * 7 : Extra Cab
- *11 : Navigation Receiver Type
- *12 : Radio & Display Receiver Type
- *13 : Radio Receiver Type
- *16 : RHD 1GD-FTV, RHD 2GD-FTV
- *17 : LHD, RHD 1KD-FTV, RHD 2KD-FTV, 1GR-FE, RHD 1TR-FE, RHD 2TR-FE
- *27 : w/ Stop & Start System
- *28 : w/o Stop & Start System

G37(A), G38(B), G40(C),
G41(D), a2(E), d1(I), d3(J)
Radio & Display Receiver Assembly
G113(K), G114(L), G115(M),
G116(N), a3(O)
Navigation Receiver Assembly
G117(F), G118(G), G119(H)
Radio Receiver Assembly






G37(A), G38(B), G40(C),
G41(D), a2(E), d1(I), d3(J)
Radio & Display Receiver Assembly
G113(K), G114(L), G115(M),
G116(N), a3(O)
Navigation Receiver Assembly
G117(F), G118(G), G119(H)
Radio Receiver Assembly




G37(A), G38(B), G40(C),
G41(D), a2(E), d1(I), d3(J)
Radio & Display Receiver Assembly
G113(K), G114(L), G115(M),
G116(N), a3(O)
Navigation Receiver Assembly
G117(F), G118(G), G119(H)
Radio Receiver Assembly



- *11 : Navigation Receiver Type
- *12 : Radio & Display Receiver Type
- *13 : Radio Receiver Type
- *15 : w/ Input Jack
- *20 : w/ Microphone
- *21 : w/ Navigation ECU
- *29 : w/ Telematics System
- *30 : w/o Telematics System

: There is no wire color information.

G37(A), G38(B), G40(C),
G41(D), a2(E), d1(I), d3(J)
Radio & Display Receiver Assembly
G113(K), G114(L), G115(M),
G116(N), a3(O)
Navigation Receiver Assembly
G117(F), G118(G), G119(H)
Radio Receiver Assembly




a1

No. 1 Stereo Jack Adapter Assembly

- * 9 : w/ Steering Pad Switch Assembly
- *11 : Navigation Receiver Type
- *12 : Radio & Display Receiver Type
- *13 : Radio Receiver Type
- *22 : *11, *12


: There is no wire color information.

G37(A), G38(B), G40(C),
G41(D), a2(E), d1(I), d3(J)
Radio & Display Receiver Assembly
G113(K), G114(L), G115(M),
G116(N), a3(O)
Navigation Receiver Assembly
G117(F), G118(G), G119(H)




a1
No. 1 Stereo Jack Adapter Assembly


G37(A), G38(B), G40(C),
G41(D), a2(E), d1(I), d3(J)
Radio & Display Receiver Assembly
G113(K), G114(L), G115(M),
G116(N), a3(O)
Navigation Receiver Assembly
G117(F), G118(G), G119(H)















A3
Gray




90980-12687

A4
Black




90980-12B01

C24
Gray



90980-12362

C51
Gray




90980-11051

C62
Black




90980-11143

C67
Black




90980-11661

C115
Black




90980-12B54


G4
Black




90980-12370




90980-12557




90980-12554




90980-12555




90980-12554




90980-10997




90980-10996




90980-12B54




90980-12B54



90980-12B54




90980-12B54




90980-12B54

G61
Black




90980-12B54

G62
Black




90980-12B54

G63
White




90980-12737


G67
White




90980-12A58




G68
White



90980-12A58




G93
Black




90980-12B54

G94
Black




90980-12B54

G95
Black




90980-12B54

G105
Black




90980-12B54

G108
Black




90980-12B54

G113
White




90980-12555

G114
White




90980-12554

G115
White




90980-10997

G116
White




90980-10996

G117
White




90980-12555

G118
White




90980-10997


G119
White




90980-10996



82824-12510



90980-12912




90980-12817




90980-12355




90980-12355




90980-12355




90980-11723




90980-12304



90980-11723




90980-12304




90980-11723




90980-11723




90980-10871




90980-12790




90980-12553




90980-12A69




90980-12A52




90980-12A52




90980-12960




90980-12960




90980-12221



90980-12976




90980-12559




90980-12370

AG1
White




90980-12414




90980-12413

AG2
White




90980-12739




90980-12738

CG1
White




90980-12A22




90980-12377

CG2

White




90980-12741




90980-12740

GN1

White




82824-52530




82824-52520

GN2

White




82824-52530




82824-52520

GN3

White




90980-12771




90980-12770

JG1

White




90980-12A22




90980-12377

KG1

White




90980-12A22




90980-12377

LN1

White




82824-52530




82824-52520

LN2

White



90980-12767



90980-12766

