

EQUIPMENT

Ohmmeter	-
Service wire	-
Torque wrench	-

EQUIPMENT

Ohmmeter	-
Radiator cap tester	-
Thermometer	-
Torque wrench	-
Slide calipers	-
Heater	-

COOLANT

Capacity	Classification
6.8 liters (7.2 US qts, 5.9 Imp. qts)	Use only "TOYOTA Super Long Life Coolant" or similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, non-borate coolant with long-life hybrid organic acid technology (coolant with long-life hybrid organic acid technology consists of a combination of low phosphates and organic acids).

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT

Ammeter	-
Ohmmeter	-
Service wire	-
Torque wrench	-

EQUIPMENT

Soft jaw vise	Skid control sensor
Torque wrench	-

LUBRICANT

Item	Capacity	Classification
Brake fluid	-	SAE J1703 or FMVSS No. 116 DOT3




EQUIPMENT

Soft jaw vise	Skid control sensor
Torque wrench	-

LUBRICANT

Item	Capacity	Classification
Brake fluid	-	SAE J1703 or FMVSS No. 116 DOT3

RECOMMENDED TOOLS

	09011-12301	Socket Wrench 30 mm	-
	09040-00011	Hexagon Wrench Set	-
	(09043-20060)	Socket Hexagon Wrench 6	-
	(09043-20120)	Socket Hexagon Wrench 12	-
	09043-50100	Bi-hexagon Wrench 10 mm	-
	09044-00020	Torx Socket E10	-
	09090-04020	Engine Sling Device	-
	(09857-00031)	Spark Plug Gap Gauge	-

PP







EQUIPMENT

V-block	-
Piston ring compressor	-
Piston ring expander	-
Valve seat cutter	-
Feeler gauge	-
CO/HC meter	-
Connecting rod aligner	-
Cylinder gauge	-
Micrometer	-
Precision straight edge	-
Radiator cap tester	-
Steel square	-
Tachometer	-
Torque wrench	-
Vernier calipers	-
Dial indicator with magnetic base	-
Alignment tester	-
toe-in gauge	-
Spring tension gauge	-
Slide calipers	-
Sandpaper (#400)	-
Piston heater	-
Wooden block	-
Plastigage	-
Angle gauge	-
Timing light	-

SSM

Toyota Genuine Seal Packing Black, Three Bond 1207B or Equivalent	-
Toyota Genuine Adhesive 1324, Three Bond 1324 or Equivalent	-
Toyota Genuine Adhesive, Three Bond 1344 or Equivalent	-

RECOMMENDED TOOLS

	09040-00011	Hexagon Wrench Set	-
	(09043-20050)	Socket Hexagon Wrench 5	-
	(09043-20100)	Socket Hexagon Wrench 10	-
	09043-50100	Bi-hexagon Wrench 10 mm	-
	09044-00010	Torx Socket E14	-
	09044-00020	Torx Socket E10	-
	09090-04020	Engine Sling Device	-
	(09857-00031)	Spark Plug Gap Gauge	-

EQUIPMENT

Alignment tester	-
Angle gauge	-
Brass bar	-
Caliper gauge	-
Chain block	-
Compression gauge	-
CO/HC meter	-
Connecting rod aligner	-
Cylinder gauge	-
Dial indicator with magnetic base	-
Engine stand	-
Feeler gauge	-
Gasket scraper	-
Magnetic finger	-
Micrometer	-
Needle-nose pliers	-
No. 1 engine hanger	-
No. 2 engine hanger	-
Pin hole grinder	-
Piston ring compressor	-
Piston ring expander	-
Piston heater	-
Plastigage	-
Plastic-faced hammer	-
Press	-
Radiator cap tester	-
Reamer (5.5 mm)	-
Ridge reamer	-
Rod aligner	-
Sandpaper (#400)	-
Slide calipers	-
Straightedge	-
Spring scale	-
Spring tension gauge	-
Steel square	-
Tachometer	-
Timing light	-
Toe-in gauge	-
Torque wrench	-
Valve seat cutter	-
V-block	-
Vernier calipers	-
Vise	-
Wooden block	-

SSM

Toyota Genuine Seal Packing Black, Three Bond 1207B or Equivalent	-
Toyota Genuine Adhesive 1324, Three Bond 1324 or Equivalent	-
Toyota Genuine Adhesive, Three Bond 1344 or Equivalent	-

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT

Clip	-
Plastic bag	-
Torque wrench	-
Vernier caliper	-

EQUIPMENT

Ohmmeter	-
Plastic bag	-
Torque wrench	-
Vernier caliper	-

EQUIPMENT

Torque wrench	-
Vacuum gauge	-
Hose clipper	-
Pressure gauge	-

SSM

Toyota Genuine Adhesive 1324, Three Bond 1324 or Equivalent	-
---	---

EQUIPMENT

Ohmmeter	-
Pressure gauge	-
Torque wrench	-
Vacuum gauge	-

SSM

Toyota Genuine Adhesive 1324, Three Bond 1324 or Equivalent	-
---	---

SSM

Toyota Genuine Seal Packing Black, Three Bond 1207B or Equivalent	-
---	---

EQUIPMENT

Ohmmeter	-
Radiator cap tester	-
Thermometer	-
Torque wrench	-
Side calipers	-
Heater	-

COOLANT

Item	Capacity	Classification
STD (A/T)	8.9 liters (9.4 US qts, 7.8 Imp. qts)	Use only "TOYOTA Super Long Life Coolant" or similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, non-borate, coolant with long-life hybrid organic acid technology (coolant with long-life hybrid organic acid technology consists of a combination of low phosphates and organic acids).
TWG (A/T)	9.3 liters (9.8 US qts, 8.2 Imp. qts)	

PP

SSM

Toyota Genuine Adhesive 1344, Three Bond 1344 or Equivalent	-
---	---

EQUIPMENT

Feeler gauge	-
Precision straight edge	-
Torque wrench	-
Vernier calipers	-
Wooden block	-



LUBRICANT

Item	Condition	Capacity	Classification
Oil grade	-	-	Use API grade SL "Energy-Conserving" or ILSAC multigrade engine oil. SAE 5W-20 and SAE 0W-20 engine oil may be used. However, SAE0W-20 is the best choice for good fuel economy and good starting in cold weather.
Drain and refill	with oil filter change	4.3 liters (4.5 US qts, 3.8 Imp. qts)	-
	without oil filter change	4.1 liters (4.3 US qts, 3.6 Imp. qts)	-
Dry fill	Dry fill	5.0 liters (5.3 US qts, 4.4 Imp. qts)	-

SSM

Toyota Genuine Adhesive 1344, Three Bond 1344B or Equivalent	-
--	---

EQUIPMENT

Container	-
Deep socket wrench (24 mm)	-
Hose	Oil filter
Oil pressure gauge	-
Socket wrench (27 mm)	-
Straightedge	-
Torque wrench	-
Wooden block	-

LUBRICANT

Item		Capacity	Classification
Oil grade		-	ILSAC multigrade engine oil is recommended. SAE 5W-30 is the best choice for good fuel economy and good starting in cold weather.
Drain and refill	With oil filter change	6.1 liters (6.4 US qts, 5.4 Imp. qts)	-
	Without oil filter change	5.7 liters (6.0 US qts, 5.0 Imp. qts)	-
Dry fill		6.5 liters (6.9 US qts, 5.7 Imp. qts)	-

PP

SSM

Toyota Genuine Adhesive 1344, Three Bond 1344 or Equivalent	-
Toyota Genuine Seal Packing Block, Three Bond 1207B or Equivalent	-
Toyota Genuine Seal Packing 1282B, Three Bond 1282B or Equivalent	-









RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT

Ammeter	-
Ohmmeter	-
Service wire	-
Torque wrench	-
Vernier calipers	-

RECOMMENDED TOOLS

	09011-12301	Socket Wrench 30 mm	-
	09031-00030	Pin Punch	-
	09031-00040	Pin Punch .	-
	09040-00011	Hexagon Wrench Set	-
	(09043-20050)	Socket Hexagon Wrench 5	-
	(09043-20060)	Socket Hexagon Wrench 6	-
	(09043-20100)	Socket Hexagon Wrench 10	-
	09070-20010	Moulding Remover	-
	09090-04020	Engine Sling Device	-
	09905-00012	Snap Ring No.1 Expander	-
	09905-00013	Snap Ring Pliers	-

EQUIPMENT

Straight edge	
Torque wrench	
Vernier calipers	
Dial indicator with magnetic base	
Slide calipers	
Chain block	
Feeler gauge	
Plastic hammer	
Press	

LUBRICANT









Automatic transaxle fluid

Dry fill	8.1 liter (8.6 US qts, 7.1 Imp.qts)	Toyota Genuine ATF WS
Drain and refill	3.6 liter (3.8 US qts, 3.2 Imp.qts)	

SSM

Toyota Genuine Seal Packing 1281 Three Bond 1281 or Equivalent	-
Toyota Genuine Adhesive 1344 Three Bond 1344 or Equivalent	-

RECOMMENDED TOOLS

	09011-12301	Socket Wrench 30 mm	-
	09031-00030	Pin Punch	-
	09031-00040	Pin Punch .	-
	09040-00011	Hexagon Wrench Set	-
	(09043-20050)	Socket Hexagon Wrench 5	-
	(09043-20060)	Socket Hexagon Wrench 6	-
	(09043-20100)	Socket Hexagon Wrench 10	-
	09070-20010	Moulding Remover	-
	09090-04020	Engine Sling Device	-
	09905-00012	Snap Ring No.1 Expander	-
	09905-00013	Snap Ring Pliers	-

EQUIPMENT

Straight edge	
Torque wrench	
Vernier calipers	
Dial indicator with magnetic base	
Slide calipers	
Chain block	
Feeler gauge	
Plastic hammer	
Press	

LUBRICANT





Automatic transaxle fluid

Dry fill	8.1 liter (8.6 US qts, 7.1 Imp.qts)	Toyota Genuine ATF WS
Drain and refill	3.6 liter (3.8 US qts, 3.2 Imp.qts)	

SSM

Toyota Genuine Seal Packing 1281 Three Bond 1281 or Equivalent	-
Toyota Genuine Adhesive 1344 Three Bond 1344 or Equivalent	-

RECOMMENDED TOOLS

	09011-12301	Socket Wrench 30 mm	-
	09031-00030	Pin Punch	-
	09040-00011	Hexagon Wrench Set	-
	(09043-20060)	Socket Hexagon Wrench 6	-
	(09043-20100)	Socket Hexagon Wrench 10	-
	09042-00010	Torx Socket T30	-
	09904-00010	Expander Set	-
	09905-00012	Snap Ring No.1 Expander	-
	09905-00013	Snap Ring Pliers	-

PP

EQUIPMENT

Straight edge	-
Vernier calipers	-
Dial indicator or dial indicator with magnetic base	-
Torque wrench	-
Feeler gauge	-
Plastic-faced hammer	-
Press	-
Seal packing 2403, THREE BOND 2403 or equivalent	-








LUBRICANT

Automatic transaxle fluid Dry fill (w/ Warmer)	8.1 liters (8.6 US qts, 7.2 Imp. qts)	Toyota Genuine ATF WS
Automatic transaxle fluid Drain and refill (w/ Warmer)	3.5 liters (3.7 US qts, 3.1 Imp. qts)	

SSM

Toyota Genuine Seal Packing 1281 Three Bond 1281 or Equivalent	-
Toyota Genuine Adhesive 1344 Three Bond 1344 or Equivalent	-

RECOMMENDED TOOLS

	09011-12301	Socket Wrench 30 mm	-
	09031-00030	Pin Punch	-
	09040-00011	Hexagon Wrench Set	-
	(09043-20060)	Socket Hexagon Wrench 6	-
	(09043-20100)	Socket Hexagon Wrench 10	-
	09042-00010	Torx Socket T30	-
	09904-00010	Expander Set	-
	09905-00012	Snap Ring No.1 Expander	-
	09905-00013	Snap Ring Pliers	-

EQUIPMENT

Straight edge	-
Vernier calipers	-
Dial indicator or dial indicator with magnetic base	-
Torque wrench	-
Feeler gauge	-
Plastic-faced hammer	-
Press	-
Seal packing 2403, THREE BOND 2403 or equivalent	-


LUBRICANT

Automatic transaxle fluid Dry fill	8.1 liters (8.6 US qts, 7.2 Imp. qts)	Toyota Genuine ATF WS
Automatic transaxle fluid Drain and refill	3.5 liters (3.7 US qts, 3.1 Imp. qts)	

SSM

Toyota Genuine Seal Packing 1281 Three Bond 1281 or Equivalent	-
Toyota Genuine Adhesive 1344 Three Bond 1344 or Equivalent	-

RECOMMENDED TOOLS

	09904-00010	Expander Set	
	09905-00012	Snap Ring No.1 Expander	

EQUIPMENT

Dial indicator or dial indicator with magnetic base	
Plastic-faced hammer	
Hammer	
Press	
Torque wrench	

EQUIPMENT

Torque wench	-
Drill	-

EQUIPMENT

Torque wrench	-
---------------	---



EQUIPMENT

Torque wrench	-
Tape	To avoid surface damage

LUBRICANT

Item	Capacity	Classification
Compressor oil	-	ND-OIL 8 or equivalent

RECOMMENDED TOOLS

	09042-00010	Torx Socket T30	-
	09082-00050	TOYOTA Electrical Tester Set	-
	(09083-00150)	Test Lead Set	-

PP

EQUIPMENT

Bolt Length: 35.0 mm (1.378 in.) Pitch: 1.0 mm (0.039 in.) Diameter: 6.0 mm (0.236 in.)	Airbag disposal
Plastic bag	Airbag disposal
Tire Width: 185 mm (7.28 in.) Inner diameter: 360 mm (14.17 in.)	Airbag disposal
Tire with disc wheel Width: 185 mm (7.28 in.) Inner diameter: 360 mm (14.17 in.)	Airbag disposal
Torque wrench	-




LUBRICANT

Item	Capacity	Classification
Transfer oil	0.5 liters (0.5 US qts, 0.4 Imp. qts)	API GL-5 SAE 75W-90

SSM

Toyota Genuine Seal Packing Black, Three Bond 1207B or Equivalent	
---	--

RECOMMENDED TOOLS

	09040-00011	Hexagon Wrench Set	-
	(09043-20050)	Socket Hexagon Wrench 5	-
	(09043-20080)	Socket Hexagon Wrench 8	-
	(09043-20100)	Socket Hexagon Wrench 10	-

PP

EQUIPMENT

Chisel	
Dial indicator with magnetic base	
Plastic-faced hammer	
Torque wrench	

LUBRICANT

Item	Capacity	Classification
Rear differential oil	0.45 to 0.55 liters (0.48 to 0.58 US qts., 0.40 to 0.48 Imp. qts.)	Hypoid gear oil API GL-5 or equivalent

SSM


Toyota Genuine Seal Packing 1281 Three Bond 1281 or Equivalent	-
---	---

2AZ-FE ENGINE CONTROL SYSTEM

SST


	09817-33190	Sensor Socket Wrench	-
---	-------------	----------------------	---

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

2GR-FE ENGINE CONTROL SYSTEM

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-






PP

EQUIPMENT




Ohmmeter	-
Service wire	-
Torque wrench	-



2AZ-FE ENGINE MECHANICAL

SST

	09032-00100	Oil Pan Seal Cutter	-
	09201-10000	Valve Guide Bushing Remover & Replacer Set	-
	(09201-01050)	Valve Guide Bushing Remover & Replacer 5	-
	09201-41020	Valve Stem Oil Seal Replacer	-
	09202-70020	Valve Spring Compressor	-
	(09202-00010)	Attachment	-
	09213-54015	Crankshaft Pulley Holding Tool	-
	(91651-60855)	Bolt	-
	09216-42010	Belt Tension Wrench Set	-
	09223-15030	Oil Seal & Bearing Replacer	-
	09223-22010	Crankshaft Front Oil Seal Replacer	-





PP

	09309-37010	Transmission Bearing Replacer	-
	09330-00021	Companion Flange Holding Tool	-
	09817-33190	Sensor Socket Wrench	-
	09843-18030	Tacho-pulse Pickup Wire No.2	-
	09843-18040	Diagnosis Check Wire No.2	-
	09950-40011	Puller B Set	-
	(09957-04010)	Attachment	-
	09950-50013	Puller C Set	-
	(09951-05010)	Hanger 150	-
	(09952-05010)	Slide Arm	-
	(09953-05020)	Center Bolt 150	-
	(09954-05021)	Claw No.2	-





	09950-60010	Replacer Set	-
	(09951-00200)	Replacer 20	-
	09950-70010	Handle Set	-
	(09951-07100)	Handle 100	-
	09992-00500	Compression Gauge Attachment	-

2GR-FE ENGINE MECHANICAL

SST




	09201-10000	Valve Guide Bushing Remover & Replacer Set	-
	(09201-01050)	Valve Guide Bushing Remover & Replacer 5	-
	09201-41020	Valve Stem Oil Seal Replacer	-
	09202-70020	Valve Spring Compressor	-
	(09202-00010)	Attachment	-
	09213-70011	Crankshaft Pulley Holding Tool	-
	(09213-70020)	Bolt	-
	09222-30010	Connecting Rod Bushing Remover & Replacer	-
	09223-15030	Oil Seal & Bearing Replacer	-
	09276-75010	Valve Lifter Tool	-
	09330-00021	Companion Flange Holding Tool	-

PP

	09843-18040	Diagnosis Check Wire No.2	-
	09950-50013	Puller C Set	-
	(09951-05010)	Hanger 150	-
	(09952-05010)	Slide Arm	-
	(09953-05020)	Center Bolt 150	-
	(09954-05021)	Claw No.2	-
	09950-60010	Replacer Set	-
	(09951-00340)	Replacer 34	-
	09950-70010	Handle Set	-
	(09951-07100)	Handle 100	-

2AZ-FE FUEL




SST

	09268-21010	Fuel Hose Puller	-
	09268-31011	Injection Measuring Tool Set	-
	(09268-41110)	Adaptor	-
	(09268-41130)	Adapter	-
	(09268-41310)	Clamp	-
	(09268-41500)	Fuel Tube Connector	-
	(90467-13001)	Clip	-
	(95336-08070)	Hose	-
	09268-45014	EFI Fuel Pressure Gauge	-
	(09268-41200)	Gauge	-
	(09268-41220)	Hose	-


	(09268-41250)	T Joint	-
	09842-30080	Wire H EFI Inspection	-

2GR-FE FUEL

SST

	09268-41048	Injection Measuring Tool Set	-
	(09268-41130)	Adapter	-
	(09268-41500)	Fuel Tube Connector	-
	(90467-13001)	Clip	-
	(95336-08070)	Hose	-
	09268-41400	Clamp	-
	09268-45014	EFI Fuel Pressure Gauge	-
	(09268-41200)	Gauge	-
	(09268-41220)	Hose	-
	(09268-41250)	T Joint	-
	09842-30080	Wire H EFI Inspection	-

RECOMMENDED TOOLS


	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

2AZ-FE EMISSION CONTROL

SST

	09224-00010	O2 Sensor Wrench	-
---	-------------	------------------	---

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

PP

2GR-FE EMISSION CONTROL

SST

	09224-00010	O2 Sensor Wrench	-
---	-------------	------------------	---

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

2GR-FE INTAKE

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT

Intelligent tester	-
Vacuum pump	-

2AZ-FE EXHAUST

EQUIPMENT

Torque wrench	-
Vernier calipers	-

2GR-FE EXHAUST

EQUIPMENT

Torque wrench	-
Vernier calipers	-

2AZ-FE COOLING

SST

	09960-10010	Variable Pin Wrench Set	-
	(09962-01000)	Variable Pin Wrench Arm Assembly	-
	(09963-00700)	Pin 7	-

PP

RECOMMENDED TOOLS


	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

2GR-FE COOLING

SST

	09960-10010	Variable Pin Wrench Set	-
	(09962-01000)	Variable Pin Wrench Arm Assembly	-
	(09963-00700)	Pin 7	-

RECOMMENDED TOOLS


	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

2AZ-FE LUBRICATION

SST


	09228-06501	Oil Filter Wrench	-
---	-------------	-------------------	---

RECOMMENDED TOOLS

	09044-00020	Torx Socket E10	-
---	-------------	-----------------	---

2GR-FE LUBRICATION

SST

	09032-00100	Oil Pan Seal Cutter	-
	09228-06501	Oil Filter Wrench	-
	09316-60011	Transmission & Transfer Bearing Replacer	-
	(09316-00011)	Replacer Pipe	-

RECOMMENDED TOOLS

	09200-00010	Engine Adjust Kit	-
---	-------------	-------------------	---

2AZ-FE IGNITION

RECOMMENDED TOOLS


	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT

Ohmmeter	-
Torque wrench	-
Voltmeter	-

2GR-FE IGNITION

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

PP

EQUIPMENT

Ohmmeter	-
Voltmeter	-
Megohmmeter	-
Spark plug cleaner	-
Torque wrench	-

2AZ-FE STARTING

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT

Ammeter(A)	-
Ohmmeter	-
Torque wrench	-
Service Wire Harness	-
Vernier calipers	-

2GR-FE STARTING

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-






PP

EQUIPMENT

Ammeter	-
Ohmmeter	-
Torque wrench	-
Service wire harness	-
Vernier calipers	-

2AZ-FE CHARGING







SST

	09820-63020	Alternator Pulley Wrench Set	-
	09950-40011	Puller B Set	-
	(09951-04020)	Hanger 200	-
	(09952-04010)	Slide Arm	-
	(09953-04020)	Center Bolt 150	-
	(09954-04010)	Arm 25	-
	(09955-04071)	Claw No.7	-
	(09957-04010)	Attachment	-
	09950-60010	Replacer Set	-
	(09951-00250)	Replacer 25	-
	09950-70010	Handle Set	-

	(09951-07100)	Handle 100	-
---	---------------	------------	---

2GR-FE CHARGING




SST

	09820-63020	Alternator Pulley Wrench Set	-
	09950-40011	Puller B Set	-
	(09951-04020)	Hanger 200	-
	(09952-04010)	Slide Arm	-
	(09953-04020)	Center Bolt 150	-
	(09954-04010)	Arm 25	-
	(09955-04071)	Claw No.7	-
	(09957-04010)	Attachment	-
	(09958-04011)	Holder	-
	09950-60010	Replacer Set	-
	(09951-00250)	Replacer 25	-







	09950-70010	Handle Set	-
	(09951-07100)	Handle 100	-



U151E AUTOMATIC TRANSMISSION

SST



	09215-00013	Crankshaft Bearing Remover & Replacer Set B	-
	(09215-00471)	Camshaft Bearing Remover & Replacer	-
	09223-15020	Oil Seal & Bearing Replacer	-
	09223-15030	Oil Seal & Bearing Replacer	-
	09308-00010	Oil Seal Puller	-
	09316-12010	Transfer Bearing Replacer	-
	09316-60011	Transmission & Transfer Bearing Replacer	-
	(09316-00011)	Replacer Pipe	-
	09350-32014	TOYOTA Automatic Transmission Tool Set	-
	(09351-32010)	One-way Clutch Test Tool	-
	(09351-32020)	Stator Stopper	-






PP

	(09351-32070)	No.2 Piston Spring Compressor	-
	(09351-32140)	Oil Seal Replacer	-
	09387-00020	Direct Clutch Wrench	-
	09387-00030	Counter Drive Gear Holding Tool	-
	09387-00041	Bearing Puller Assembly	-
	(09387-01010)	Claw No.1	-
	(09387-01021)	Claw No.2	-
	(09387-01030)	Pin	-
	(09387-01040)	Bearing Puller Body	-
	09387-00050	Under Drive Gear Puller	-
	09387-00060	Second Brake Wrench	-
	09387-00070	First & Reverse Brake Wrench	-

	09387-00080	Counter Drive Gear Nut Wrench	-
	09502-12010	Differential Bearing Replacer	-
	09506-35010	Differential Drive Pinion Rear Bearing Replacer	-
	09514-35011	Rear Wheel Bearing Puller	-
	09527-17011	Rear Axle Shaft Bearing Remover	-
	09550-60010	Differential Side Bearing Replacer	-
	(09951-00490)	Replacer 49	-
	09564-32011	Differential Preload Adaptor	-
	09608-10010	Steering Knuckle Oil Seal Replacer	-
	09649-17010	Steering Knuckle Tool	-
	09710-30050	Suspension Arm Bushing Replacer	-
	09726-40010	Lower Control Shaft Bearing Replacer	-

PP

	09930-00010	Drive Shaft Nut Chisel	-
	(09931-00010)	Handle	-
	(09931-00020)	Nut Chisel	-
	09950-00020	Bearing Remover	-
	09950-00030	Bearing Remover Attachment	-
	09950-40011	Puller B Set	-
	(09957-04010)	Attachment	-
	09950-60010	Replacer Set	-
	(09951-00230)	Replacer 23	-
	(09951-00260)	Replacer 26	-
	(09951-00320)	Replacer 32	-
	(09951-00450)	Replacer 45	-

	(09951-00490)	Replacer 49	-
	(09951-00500)	Replacer 50	-
	(09951-00590)	Replacer 59	-
	(09952-06010)	Adapter	-
	(09957-04010)	Attachment	-
	09950-60020	Replacer Set No.2	-
	(09951-00750)	Replacer 75	-
	(09951-00810)	Replacer 81	-
	(09951-00890)	Replacer 89	-
	(09951-00910)	Replacer 91	-
	(09951-01030)	Replacer 103	-
	09950-70010	Handle Set	-








	(09951-07100)	Handle 100	-
	(09951-07150)	Handle 150	-

U151F AUTOMATIC TRANSMISSION







SST



PP


	09215-00013	Crankshaft Bearing Remover & Replacer Set B	-
	(09215-00471)	Camshaft Bearing Remover & Replacer	-
	09223-15020	Oil Seal & Bearing Replacer	-
	09223-15030	Oil Seal & Bearing Replacer	-
	09308-00010	Oil Seal Puller	-
	09350-32014	TOYOTA Automatic Transmission Tool Set	-
	(09351-32010)	One-way Clutch Test Tool	-
	(09351-32020)	Stator Stopper	-
	(09351-32070)	No.2 Piston Spring Compressor	-
	(09351-32140)	Oil Seal Replacer	-
	09387-00020	Direct Clutch Wrench	-

	09387-00030	Counter Drive Gear Holding Tool	-
	09387-00041	Bearing Puller Assembly	-
	(09387-01010)	Claw No.1	-
	(09387-01021)	Claw No.2	-
	(09387-01030)	Pin	-
	(09387-01040)	Bearing Puller Body	-
	09387-00050	Under Drive Gear Puller	-
	09387-00060	Second Brake Wrench	-
	09387-00070	First & Reverse Brake Wrench	-
	09387-00080	Counter Drive Gear Nut Wrench	-
	09502-12010	Differential Bearing Replacer	-
	09506-35010	Differential Drive Pinion Rear Bearing Replacer	-

PP

	09514-35011	Rear Wheel Bearing Puller	-
	09527-17011	Rear Axle Shaft Bearing Remover	-
	09550-60010	Differential Side Bearing Replacer	-
	09564-32011	Differential Preload Adaptor	-
	09608-10010	Steering Knuckle Oil Seal Replacer	-
	09649-17010	Steering Knuckle Tool	-
	09710-30050	Suspension Arm Bushing Replacer	-
	09726-40010	Lower Control Shaft Bearing Replacer	-
	09930-00010	Drive Shaft Nut Chisel	-
	(09931-00010)	Handle	-
	(09931-00020)	Nut Chisel	-
	09950-00020	Bearing Remover	-

	09950-00030	Bearing Remover Attachment	-
	09950-40011	Puller B Set	-
	(09957-04010)	Attachment	-
	09950-60010	Replacer Set	-
	(09951-00230)	Replacer 23	-
	(09951-00260)	Replacer 26	-
	(09951-00320)	Replacer 32	-
	(09951-00450)	Replacer 45	-
	(09951-00500)	Replacer 50	-
	(09951-00590)	Replacer 59	-
	(09952-06010)	Adapter	-
	(09957-04010)	Attachment	-



09950-60020

Replacer Set No.2

-



(09951-00680)

Replacer 68

-



(09951-00750)

Replacer 75

-



(09951-00810)

Replacer 81

-



(09951-00890)

Replacer 89

-



(09951-00910)

Replacer 91


-



(09951-01030)

Replacer 103

-



09950-70010

Handle Set

-



(09951-00890)

Replacer 89

-



(09951-07100)

Handle 100

--



(09951-0750)

Handle 150

-








(09951-07200)

Handle 200






-







U140F AUTOMATIC TRANSAXLE

SST




	09214-76011	Crankshaft Pulley Replacer	-
	09215-00013	Crankshaft Bearing Remover & Replacer Set B	-
	(09215-00471)	Camshaft Bearing Remover & Replacer	-
	09223-15020	Oil Seal & Bearing Replacer	-
	09308-00010	Oil Seal Puller	-
	09309-37010	Transmission Bearing Replacer	-
	09350-32014	TOYOTA Automatic Transmission Tool Set	-
	(09351-32010)	One-way Clutch Test Tool	-
	(09351-32020)	Stator Stopper	-
	(09351-32070)	No.2 Piston Spring Compressor	-
	(09351-32140)	Oil Seal Replacer	-

PP

	09387-00020	Direct Clutch Wrench	-
	09387-00030	Counter Drive Gear Holding Tool	-
	09387-00041	Bearing Puller Assembly	-
	(09387-01010)	Claw No.1	-
	(09387-01030)	Pin	-
	(09387-01040)	Bearing Puller Body	-
	09387-00050	Under Drive Gear Puller	-
	09387-00060	Second Brake Wrench	-
	09387-00070	First & Reverse Brake Wrench	-
	09387-00080	Counter Drive Gear Nut Wrench	-
	09514-35011	Rear Wheel Bearing Puller	-
	09550-60010	Differential Side Bearing Replacer	-

	09564-16020	Drive Pinion Lock Nut Wrench	-
	09564-32011	Differential Preload Adaptor	-
	09608-10010	Steering Knuckle Oil Seal Replacer	-
	09649-17010	Steering Knuckle Tool	-
	09710-30050	Suspension Arm Bushing Replacer	-
	09726-27012	Front Suspension Arm Bushing Remover & Replacer	-
	(09726-02041)	Replacer	-
	09930-00010	Drive Shaft Nut Chisel	-
	(09931-00010)	Handle	-
	(09931-00020)	Nut Chisel	-
	09950-00020	Bearing Remover	-
	09950-00030	Bearing Remover Attachment	-




PP

	09950-60010	Replacer Set	-
	(09951-00230)	Replacer 23	-
	(09951-00320)	Replacer 32	-
	(09951-00340)	Replacer 34	-
	(09951-00450)	Replacer 45	-
	(09951-00500)	Replacer 50	-
	(09951-00580)	Replacer 58	-
	(09952-06010)	Adapter	-
	09950-60020	Replacer Set No.2	-
	(09951-00680)	Replacer 68	-
	(09951-00750)	Replacer 75	-
	(09951-00810)	Replacer 81	-




	(09951-00890)	Replacer 89	-
	09950-70010	Handle Set	-
	(09951-00890)	Replacer 89	-
	(09951-07100)	Handle 100	-
	(09951-07150)	Handle 150	-
	(09951-07200)	Handle 200	-






U241E AUTOMATIC TRANSAXLE

SST






	09308-00010	Oil Seal Puller	-
	09316-60011	Transmission & Transfer Bearing Replacer	-
	(09316-00011)	Replacer Pipe	-
	09350-32014	TOYOTA Automatic Transmission Tool Set	-
	(09351-32010)	One-way Clutch Test Tool	-
	(09351-32020)	Stator Stopper	-
	(09351-32070)	No.2 Piston Spring Compressor	-
	(09351-3240)	Oil Seal Replacer	-
	(09351-32150)	Oil Seal Replacer	-
	09387-00020	Direct Clutch Wrench	-
	09387-00030	Counter Drive Gear Holding Tool	-

PP

	09387-00041	Bearing Puller Assembly	-
	(09387-01010)	Claw No.1	-
	(09387-01030)	Pin	-
	(09387-01040)	Bearing Puller Body	-
	(09387-02010)	Oil Seal Replacer	-
	(09387-02020)	One-way Clutch Test Tool Set	-
	09387-00050	Under Drive Gear Puller	-
	09387-00060	Second Brake Wrench	-
	09387-00070	First & Reverse Brake Wrench	-
	09387-00080	Counter Drive Gear Nut Wrench	-
	09506-35010	Differential Drive Pinion Rear Bearing Replacer	-
	09514-35011	Rear Wheel Bearing Puller	-

	09550-60010	Differential Side Bearing Replacer	-
	(09951-00320)	Replacer 32	-
	09564-16020	Drive Pinion Lock Nut Wrench	-
	09564-32011	Differential Preload Adaptor	-
	09608-06041	Front Hub Inner Bearing Cone Replacer	-
	09608-32010	Steering Knuckle Oil Seal Replacer	-
	09649-17010	Steering Knuckle Tool	-
	09930-00010	Drive Shaft Nut Chisel	-
	(09931-00010)	Handle	-
	(09931-00020)	Nut Chisel	-
	09950-00020	Bearing Remover	-
	09950-00030	Bearing Remover Attachment	-

PP

	09950-40011	Puller B Set	-
	(09951-04010)	Hanger 150	-
	(09951-04020)	Hanger 200	-
	(09952-04010)	Slide Arm	-
	(09953-04020)	Center Bolt 150	-
	(09954-04010)	Arm 25	-
	(09955-04011)	Claw No.1	-
	(09955-04061)	Claw No.6	-
	(09957-04010)	Attachment	-
	(09958-04011)	Holder	-
	09950-60010	Replacer Set	-
	(09951-00230)	Replacer 23	-

	(09951-00250)	Replacer 25	-
	(09951-00320)	Replacer 32	-
	(09951-00340)	Replacer 34	-
	(09951-00350)	Replacer 35	-
	(09951-00400)	Replacer 40	-
	(09951-00450)	Replacer 45	-
	(09951-00600)	Replacer 60	-
	09950-60020	Replacer Set No.2	-
	(09951-00680)	Replacer 68	-
	(09951-00710)	Replacer 71	-
	(09951-00890)	Replacer 89	-
	(09951-07150)	Handle 150	-







	09950-70010	Handle Set	-
	(09951-07100)	Handle 100	-
	(09951-07150)	Handle 150	-







PP

GF1A TRANSFER




SST

PP

	09308-00010	Oil Seal Puller	
	09310-35010	Countershaft Bearing Replacer	
	09316-12010	Transfer Bearing Replacer	
	09316-60011	Transmission & Transfer Bearing Replacer	
	(09316-00011)	Replacer Pipe	
	09336-16010	Wrench 55 x 32 mm	
	09612-10093	Steering Gear Housing Overhaul Tool Set	
	(09612-10061)	Steering Pinion Bearing Replacer	
	09636-20010	Upper Ball Joint Dust Cover Replacer	
	09930-00010	Drive Shaft Nut Chisel	
	09950-00020	Bearing Remover	

	09950-40011	Puller B Set	
	(09951-04010)	Hanger 150	
	(09952-04010)	Slide Arm	
	(09953-04020)	Center Bolt 150	
	(09953-04030)	Center Bolt 200	
	(09954-04010)	Arm 25	
	(09955-04061)	Claw No.6	
	(09957-04010)	Attachment	
	(09958-04011)	Holder	
	09950-60010	Replacer Set	
	(09951-00220)	Replacer 22	
	(09951-00400)	Replacer 40	

PP

	(09951-00440)	Replacer 44	
	(09951-00540)	Replacer 54	
	(09951-00560)	Replacer 56	
	(09951-00620)	Replacer 62	
	(09952-06010)	Adapter	
	09950-60020	Replacer Set No.2	
	(09951-00750)	Replacer 75	
	(09952-06010)	Adapter	
	09950-70010	Handle Set	
	(09951-07100)	Handle 100	
	(09951-07150)	Handle 150	

PROPELLER SHAFT

SST





	09370-50010	Drive Line Angle Gauge	-
---	-------------	------------------------	---

EQUIPMENT

Dial indicator with magnetic base	
Torque wrench	
V - block	
Vernier calipers	

DRIVE SHAFT

SST

	09520-01010	Drive Shaft Remover Attachment	-
	09520-24010	Differential Side Gear Shaft Puller	-
	(09520-32040)	Shocker Set	-
	09527-10011	Rear Axle Shaft Bearing Remover	-
	09608-16042	Front Hub Bearing Adjusting Tool	-
	(09608-02021)	Bolt & Nut	-
	(09608-02041)	Retainer	-
	09710-04081	Base	-
	09726-40010	Lower Control Shaft Bearing Replacer	-
	09950-00020	Bearing Remover	-






EQUIPMENT









Dial indicator with magnetic base	
Micrometer	
Torque wrench	

DIFFERENTIAL



SST




PP

	09223-00010	Cover & Seal Replacer	-
	09223-50010	Crankshaft Front Oil Seal Replacer	-
	09308-00010	Oil Seal Puller	-
	09308-10010	Oil Seal Puller	-
	09506-30012	Differential Drive Pinion Rear Bearing Cone Replacer	-
	09556-16011	Differential Drive Pinion Holding Tool	-
	09556-30010	Drive Pinion Front Bearing Remover	-
	09564-16020	Drive Pinion Lock Nut Wrench	-
	09564-32011	Differential Preload Adaptor	-
	09612-07010	Main Shaft Retaining Ring Remover & Replacer	-
	(09612-10061)	Steering Pinion Bearing Replacer	-

	09612-65014	Steering Worm Bearing Puller	-
	(09612-01020)	Claw B	-
	(09612-01050)	Hanger Pin with Nut	-
	09649-17010	Steering Knuckle Tool	-
	(09951-00510)	Replacer 51	-
	09710-30021	Suspension Bushing Tool Set	-
	(09710-03121)	Bushing Remover Base	-
	09930-00010	Drive Shaft Nut Chisel	-
	09950-00020	Bearing Remover	-
	09950-40011	Puller B Set	-
	(09951-04010)	Hanger 150	-
	(09952-04010)	Slide Arm	-


PP

	(09953-04020)	Center Bolt 150	-
	(09954-04010)	Arm 25	-
	(09955-04061)	Claw No.6	-
	(09957-04010)	Attachment	-
	(09958-04011)	Holder	-
	09950-60010	Replacer Set	-
	(09951-00320)	Replacer 32	-
	(09951-00460)	Replacer 46	-
	(09951-00510)	Replacer 51	-
	(09951-00550)	Replacer 55	-
	(09951-00570)	Replacer 57	-
	(09951-00600)	Replacer 60	-

	(09951-00620)	Replacer 62	-
	(09952-06010)	Adapter	-
	(09955-04071)	Claw No.7	-
	09950-60020	Replacer Set No.2	-
	(09951-00680)	Replacer 68	-
	(09951-00750)	Replacer 75	-
	09950-70010	Handle Set	-
	(09951-07100)	Handle 100	-
	(09951-07150)	Handle 150	-

AXLE

SST

	09650-17011	Hub Bolt Remover	-
	09930-00010	Drive Shaft Nut Chisel	-







EQUIPMENT

Dial indicator with magnetic base	
Micrometer	
Torque wrench	

SUSPENSION

SST

PP

	09610-20012	Pitman Arm Puller	-
	09628-62011	Boll Joint Puller	-
	09670-00020	Front Crossmember Guide Tool	-
	09727-30021	Coil Spring Compressor	-
	(09727-00010)	Bolt Set	-
	(09727-00021)	Arm Set	-
	(09727-00031)	Compressor	-
	09729-22031	Front Spring Upper Seat Holder	-
	09961-01270	Torque Wrench Adapter	-

EQUIPMENT

Alignment tester	
Angle gauge	
Dial indicator with magnetic base	
Drill	
Toe-in gauge	
Torque wrench	

TIRE AND WHEEL

RECOMMENDED TOOLS



	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT


Dial indicator with magnetic base	
Tire pressure gauge	
Torque wrench	
Wheel balancer	

BRAKE CONTROL

SST



	09023-00101	Union Nut Wrench 10 mm	-
	09214-76011	Crankshaft Pulley Replacer	-
	09520-00031	Rear Axle Shaft Puller	-
	(09520-00040)	Shocker	-
	09521-00020	Drive Shaft Boot Clamping Tool	-
	09950-00020	Bearing Remover	-

RECOMMENDED TOOLS


	09031-00040	Pin Punch .	Skid control sensor
	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

BRAKE CONTROL

SST

	09023-00101	Union Nut Wrench 10 mm	-
	09214-76011	Crankshaft Pulley Replacer	-
	09520-00031	Rear Axle Shaft Puller	-
	(09520-00040)	Shocker	-
	09521-00020	Drive Shaft Boot Clamping Tool	-
	09950-00020	Bearing Remover	-

RECOMMENDED TOOLS

	09031-00040	Pin Punch .	Skid control sensor
	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

PARKING BRAKE

RECOMMENDED TOOLS



	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT


Torque wrench	
Needle-nose pliers	
Brake drum gauge	
Ruler	

STEERING COLUMN

SST


	09950-50013	Puller C Set	-
	(09951-05010)	Hanger 150	-
	(09952-05010)	Slide Arm	-
	(09953-05020)	Center Bolt 150	-
	(09954-05021)	Claw No.2	-

RECOMMENDED TOOLS


	09042-00010	Torx Socket T30	-
---	-------------	-----------------	---

POWER STEERING

SST

	09628-62011	Ball Joint Puller	-
---	-------------	-------------------	---


RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-




AIR CONDITIONING

SST

PP

	07110-58060	Air Conditioner Service Tool Set	-
	(07117-58060)	Refrigerant Drain Service Valve	-
	(07117-58070)	T-Joint	-
	(07117-58080)	Quick Disconnect Adapter	-
	(07117-58090)	Quick Disconnect Adapter	-
	(07117-78050)	Refrigerant Charging Gauge	-
	(07117-88060)	Refrigerant Charging Hose	-
	(07117-88070)	Refrigerant Charging Hose	-
	(07117-88080)	Refrigerant Charging Hose	-




RECOMMENDED TOOLS

	09040-00011	Hexagon Wrench Set	-
	(09043-20060)	Socket Hexagon Wrench 6	-
	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-
	95146-00180	Halogen Leak Detector DENSO Part No.	-

SUPPLEMENTAL RESTRAINT SYSTEM

SST


PP

	09082-00700	SRS Airbag Deployment Tool	-
	09082-00750	Airbag Deployment Wire Sub-harness No.3	-
	09082-00780	Airbag Deployment Wire Sub-harness No.6	-
	09082-00802	Airbag Deployment Wire Sub-Harness No. 8	-
	(09082-10801)	Wire A	-
	(09082-20801)	Wire B	-
	(09082-30801)	Wire C	-
	09843-18060	SRS Check Wire	-
	09950-50013	Puller C Set	-
	(09951-05010)	Hanger 150	-
	(09952-05010)	Slide Arm	-

	(09953-05020)	Center Bolt 150	-
	(09954-05021)	Claw No.2	-

SEAT BELT

SST

	09082-00700	SRS Airbag Deployment Tool	-
	09082-00770	Airbag Deployment Wire Sub-harness No.5	-


PP

EQUIPMENT

Torque wrench	
---------------	--

SEAT BELT

SST

	09082-00700	SRS Airbag Deployment Tool	-
	09082-00770	Airbag Deployment Wire Sub-harness No.5	-

PP

EQUIPMENT

Torque wrench	
---------------	--

ENGINE IMMOBILISER

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

CRUISE CONTROL

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-


PP

EQUIPMENT

Torque wrench	-
---------------	---

LIGHTING

RECOMMENDED TOOLS



	09042-00010	Torx Socket T30	-
	(09083-00150)	Test Lead Set	-
	09082-00040	TOYOTA Electrical Tester	-

EQUIPMENT

Tape	To avoid surface damage
------	-------------------------

WIPER AND WASHER

RECOMMENDED TOOLS

	09042-00010	Torx Socket T30	-
	(09083-00150)	Test Lead Set	-
	09082-00040	TOYOTA Electrical Tester	-

PP

EQUIPMENT

Torque wrench	
Tape	To avoid surface damage


DOOR LOCK

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

METER

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

PP

HORN

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-


PP

EQUIPMENT

Torque wrench	
---------------	--

MIRROR

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

PP

EQUIPMENT

Tape	To avoid surface damage
Torque wrench	


INSTRUMENT PANEL

EQUIPMENT

Tape	To avoid surface damage
Torque wrench	-

SEAT

RECOMMENDED TOOLS

	09042-00010	Torx Socket T30	-
	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-
	09200-00010	Engine Adjust Kit	-



PP

EQUIPMENT

Clip remover	
Hog ring	
Hog ring pliers	
Protective tape	To avoid surface damage
Tacker	
Tack pin	
Torque wrench	

EXTERIOR

RECOMMENDED TOOLS

	09050-00032	Air Drill	-
	09050-20010	Air Riveter	-
	09070-20010	Moulding Remover	-

EQUIPMENT

Cleaner	
Clip remover	
Double-sided tape	
Hand riveter	
Protective tape	To avoid surface damage
Torque wrench	


INTERIOR

EQUIPMENT

Clip remover	
Double-sided tape	
Protective tape	To avoid surface damage

SLIDING ROOF

RECOMMENDED TOOLS

	09041-00020	Torx Driver T25	-
	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT

Torque wrench	
---------------	--

CAN COMMUNICATION

RECOMMENDED TOOLS

	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-