


Oldsmobile Bravada 2002 fuse box diagram

Engine Compartment Fuse Block

The fuse block is located under the hood in the engine compartment on the driver's side of the vehicle.



Oldsmobile Bravada – fuse box – engine

compartment

Mini Fuse	Usage
1	ECAS
2	Passenger's Side High-Beam Headlamp
3	Passenger's Side Low-Beam Headlamp
4	Back-Up Trailer Lamps
5	Driver's Side High-Beam Headlamp
6	Driver's Side Low-Beam Headlamp
7	WASH
8	ATC
9	Windshield Wipers
10	Powertrain Control Module B
11	Fog Lamps
12	ST/LP
13	Cigarette Lighter
14	COILS
15	RIDE
16	TBD — Ignition 1
17	Crank
18	Air Bag
19	ELEK Brake
20	Cooling Fan
21	Horn
22	Ignition E
23	ETC
24	Instrument Panel Cluster, Driver Information Center
25	Automatic Shift Lock Control System

26	ENG 1
27	Back-Up
28	Powertrain Control Module 1
29	Oxygen Sensor
30	Air Conditioning
31	TBC
50	Passenger's Side Trailer TRN
51	Driver's Side Trailer TRN
52	Hazard Flashers

J-Case fuses	Usage
32	Trailer
33	Anti-Lock Brakes (ABS)
34	Ignition A
35	Blower Motor
36	Ignition B

Micro Relays	Usage
37	Blank
38	Rear Window Washer
39	Fog Lamps
40	Horn
41	Fuel Pump
42	Windshield Wipers/Washer
43	High-Beam Headlamp
44	Air Conditioning


Solid State Relays	Usage
45	Cooling Fan
46	HDM

Mini Relay	Usage
47	Starter

Miscellaneous	Usage
48	Instrument Panel Battery

Rear Underseat Fuse Block

The rear underseat fuse block is located under the rear seat on the driver's side of the vehicle.



Oldsmobile Bravada – fuse box – rear underseat fuse block

Fuse	Usage
01	Right Door Control Module
02	Left Door Control Module
03	LGM 2
04	TBC 3
05	Rear Fog Lamps
06	LGM/DSM
07	TBC 2
08	Power Seats
09	Blank
10	DDM
11	AMP
12	PDM
13	Rear Climate Controls
14	Left Rear Parking Lamps
15	Auxiliary Power 2
16	VEH CHMSL
17	Right Rear Parking Lamps
18	LOCK
19	Blank
20	Sunroof
21	LOCKS

23	Blank
24	UNLOCK
25	Blank
26	Blank
27	OH Battery/OnStar System
29	Rainsense Wipers
30	Parking Lamps
31	TBC 4CC
32	TBC 5
33	Front Wipers
34	VEH STOP
35	Blank
36	HVAC B
37	Front Parking Lamps
38	Left Turn Signal
39	HVAC 1
40	TBC 4
41	Radio
42	TR PARK
43	Right Turn Signal
44	HVAC
45	Rear Fog Lamps
46	Auxiliary Power 1
47	Ignition 0
48	All-Wheel Drive
49	Blank
50	TBC IG
51	Brakes
52	TBC RUN