

DTC	62-43	CD-ROM Abnormal
DTC	63-43	CD-ROM Abnormal

DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
62-43	CD-ROM operation is abnormal	- CD - Radio receiver
63-43	CD-ROM operation is abnormal	

INSPECTION PROCEDURE

HINT:

After the inspection is completed, clear the DTCs.

1	CHECK IF A PROPER CD IS INSERTED
----------	---

- (a) Make sure that the CD is an audio CD and that it is not deformed, flawed, stained, burred, or otherwise defective.

OK:**Normal CD**

HINT:

- Translucent or uniquely-shaped CDs cannot be played.
- CDs with adhesive paper labels should not be played.
- Commercial audio CDs can be played.
- For details on playable CDs, refer to the Owner's Manual.

NG**CHANGE DISC****OK**

2	REPLACE CD
----------	-------------------

- (a) Replace the CD with another and recheck.
- Replace the CD with another normal one.
 - Clear the DTCs (See page [AV-14](#)).
 - Recheck for DTCs and check if the same trouble occurs again.

OK:**Malfunction disappears.****NG****REPLACE RADIO RECEIVER****OK****END****AV**

DTC	62-44	CD Abnormal
DTC	62-48	Excess Current
DTC	62-50	Tray Insertion / Ejection Error
DTC	63-44	CD Abnormal
DTC	63-48	Excess Current
DTC	63-50	Tray Insertion / Ejection Error

DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
62-44	Operation error in the CD mechanism	Radio receiver
62-48	Excess current is present in the CD player	
62-50	Malfunction in insertion/ejection system	
63-44	Operation error in the CD mechanism	
63-48	Excess current is present in the CD changer	
63-50	Malfunction in insertion/ejection system	

INSPECTION PROCEDURE

HINT:

After the inspection is completed, clear the DTCs.

1	CLEAR DTC
----------	------------------

(a) Clear the DTCs (See page [AV-14](#)).**NEXT**

2	RECHECK DTC
----------	--------------------

(a) Recheck for DTCs and check if the same trouble occurs again.

HINT:

If DTCs are detected frequently, replace the radio receiver.

OK:

Malfunction disappears.

NG**REPLACE RADIO RECEIVER****OK****END**