


Power Outlet for 12V

* 1 : w/o Cigarette Lighter



 : **Parts Location**

Code	See Page	Code	See Page	Code	See Page
C8	38	J7	39		
J2	39	P6	39		

 : **Relay Blocks**

Code	See Page	Relay Blocks (Relay Block Location)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

 : **Junction Block and Wire Harness Connector**

Code	See Page	Junction Block and Wire Harness (Connector Location)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)

 : **Connector Joining Wire Harness and Wire Harness**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IJ1	45	Console Wire and Instrument Panel Wire (Front Side of the Parking Brake Lever)

 : **Ground Points**

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel