


Audio System for Built-In Amplifier



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
A17	38	R11	41	R17	B 39
F8	40	R12	41	T4	41
F9	40	R16	A 39	T5	41

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4C	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
ID1	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IH2	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BA1	46	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BB1	46	Rear Door RH Wire and Instrument Panel Wire (Right Center Pillar)

 : Ground Points

Code	See Page	Ground Points Location
IF	44	Behind Combination Meter