



Programmed Fuel Injection System (PGM-FI)

NOTE: Fuse 14 is HOT with Ignition Switch in START (III) and A/T Gear Selector in PARK (P) or NEUTRAL (N), see Starting System, page 21.

* = '99-'04

