


# Connector Views

## 65. Daytime Running Lights Control Unit (Canada)

- Left front corner of trunk
- On left side wire harness



### '96-'98:

- 1 YEL/BLU (High beam/DRL mode control)
- 2 RED/BLU (Fuse 10)
- 3 WHT/BLU (Dimmer relay input)
- 4 BLK (G401)
- 5 WHT/BLU (Dimmer relay input)
- 6 GRN/WHT (Parking brake input)
- 7 BLK (G651)
- 8 BLU/RED (Headlights ON input)
- 9 YEL (DRL indicator control)
- 10 RED/GRN (DRL output)
- 11 RED/BLU (High beam/DRL mode control)
- 12 YEL/RED (Ignition input)
- 13 GRN/RED (Brake indicator control)
- 14 —

### '99-'04:

- 1 YEL/BLU  
'99: (High beam/DRL mode control)  
'00-'04: (High beam/DRL mode control)
- 2 RED/BLU (Fuse 10)
- 3 RED/BLK  
'99: (High beam relay input)  
'00-'04: (High beam relay input)
- 4 BLK (G251)
- 5 RED/YEL  
'99: (High beam relay input)  
'00-'04: (High beam relay input)
- 6 GRN/RED (Parking brake input)
- 7 BLK (G651)
- 8 PNK (Headlights ON input)
- 9 YEL (DRL indicator control)
- 10 RED/BLU  
'99: (DRL output)  
'00-'04: (DRL output)
- 11 RED/BLU  
'99: (High beam/DRL mode control)  
'00-'04: (High beam/DRL mode control)
- 12 YEL/RED (Ignition input)
- 13 GRN/RED (Brake indicator control)
- 14 —

