



Connector Views

78. C421

- Black
- At base of steering column
- Main wire harness junction connector

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20

1 BLK/YEL (Fuse 20)	11 LT GRN/RED (DPMS)	17 GRN/RED
2 BLK/YEL (Fuse 20)	12 LT GRN/RED (DPMS)	'96-'99 USA: (Brake system indicator)
3 BLK/YEL (Fuse 20)	13 LT GRN/RED (DPMS)	'96-'99 Canada: (Brake system indicator)
4 BLK/YEL (Fuse 20)		'00-'04: (Brake system indicator)
5 BLK/YEL (Fuse 20)	14 BLK/WHT (DPMS)	18 GRN/RED
6 BLK/YEL (Fuse 20)	15 BLK/WHT (DPMS)	'96-'99 USA: (Brake system indicator)
	16 BLK/WHT (DPMS)	'96-'99 Canada: (Brake system indicator)
7 WHT/YEL (Fuse 39)		'00-'04: (Brake system indicator)
8 WHT/YEL (Fuse 39)		19 GRN/RED
9 WHT/YEL (Fuse 39)		'96-'99 USA: (Brake system indicator)
10 WHT/YEL (Fuse 39)		'96-'99 Canada: (Brake system indicator)
		'00-'04: (Brake system indicator)
		20 GRN/RED
		'96-'99 USA: (Brake system indicator)
		'96-'99 Canada: (Brake system indicator)
		'00-'04: (Brake system indicator)

Terminals grouped together are connected by the same bus bar.

