



Connector Views

82. C464

- Black
- Below right side of dash
- Main wire harness junction connector

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20

1 '96-'99: RED '96-'98: (Dash lights) '99: (Dash lights) 2 RED '96-'98: (Dash lights) '99-'04: (Dash lights) 3 RED '96-'98: (Dash lights) '99-'04: (Dash lights) 4 RED '96-'98: (Dash lights) '99-'04: (Dash lights) 5 RED '96-'98: (Dash lights) '99-'04: (Dash lights) 6 RED '96-'98: (Dash lights) '99-'04: (Dash lights)	7 YEL/BLU (PGM-FI) 8 YEL/BLU (PGM-FI) 9 YEL/BLU (PGM-FI) 10 YEL/BLU (PGM-FI) 11 '96-'98: RED/YEL (Headlight switch) '99-'04: RED/BLK (Headlight switch) 12 '96-'98: RED/YEL (Headlight switch) '99-'04: RED/BLK (Headlight switch) 13 '96-'98: RED/YEL (Headlight switch) '99-'04: RED/BLK (Headlight switch)	14 GRN/WHT (A/T controls) 15 GRN/WHT (A/T controls) 16 GRN/WHT (A/T controls) 17 WHT/BLU (Fuse 57) 18 WHT/BLU (Fuse 57) 19 WHT/BLU (Fuse 57) 20 WHT/BLU (Fuse 57)
---	--	---

Terminals grouped together are connected by the same bus bar.

