



Connector Views

137. OnStar Control Unit ('02-'04 USA)

- Behind right side of rear seat
- On OnStar system sub-harness

Connector A

– Red

Connector B

– Blue

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

1 GRY (XCVR BATT)
 2 —
 3 BRN (XCVR MIC IN)
 4 BRN (XCVR MIC GND)
 5 YEL (XCVR TX AUDIO)
 6 YEL (XCVR AX AUDIO)
 7 YEL (XCVR AUDIO GND)
 8 GRY (LINE SLD)
 9 —
 10 WHT (LINE OUT (-))
 11 BLU/RED (LINE OUT (+))
 12 —
 13 —
 14 —
 15 GRN (NOT USED)
 16 —

17 —
 18 GRY (VEH XCVR IGN)
 19 GRY (VEH XCVR GND)
 20 GRY (VEH XCVR TRU)
 21 GRY (VEH XCVR CNP)
 22 GRY (VEH XCVR RTN)
 23 BLK (VEH MIC GND)
 24 WHT (VEH MIC IN)
 25 BRN/YEL (VEH MIC SLD)
 26 —
 27 —
 28 —
 29 —
 30 —
 31 —
 32 BLK (GND)

1 —
 2 BLK (GND)
 3 RED/GRN (VEH LIGHT LO)
 4 —
 5 GRN/RED (VEH UNLOCK LO)
 6 ORN (HORN OUT LO)
 7 BLU (SRS 2)
 8 —
 9 BLK (GND)
 10 BLK (ONSTAR AUDIO MUTE)
 11 ORN (KEY PAD POWER OUT)
 12 GRN
 (KEY PAD LED OUT) (GREEN)
 13 PUR (KEY PAD IN)
 14 —
 15 —
 16 —

17 WHT/YEL (VEH BATT)
 18 BLK (GND)
 19 —
 20 GRN/WHT (VEH LOCK LO)
 21 BLU (8V ON ENABLE)
 22 WHT (VEH ACC)
 23 —
 24 PUR
 (VEH KEY PAD LED OUT) (RED)
 25 ORN (SRS 1)
 26 —
 27 —
 28 —
 29 ORN (VEH KEY PAD GND)
 30 —
 31 —
 32 BLK (GND)

