



Connector to Harness Index


Right Engine Compartment Wire Harness

Connector or Terminal	Cavities/ Color	Location	Connects to	Notes
C201	18-GRY	Under right side of dash	Main wire harness	
C202	8-GRY	Under right side of dash	Main wire harness	
C203	2-GRY	Behind right fender	Keyless buzzer	
C204	2-BLU	Behind right front side marker light	Right front side marker light	
C205	2-BRN	Behind right front turn signal light	Right front turn signal light	*1
C205	3-WHT	Behind right front turn signal/parking light	Right front turn signal/parking light	*2
C206	3	Behind right headlight	Right headlight (low/high beam)	*1
C206	2-GRY	Behind right headlight	Right headlight (low beam)	*2
C207	2	Behind right front parking light	Right front parking light	*1
C208	3	Behind right fog light	Right fog light	*1
C208	3-BLK	Behind right headlight	Right headlight (high beam)	*2
C209	4-GRY	Front of radiator	A/C pressure switch	
C210	2-GRY	Behind middle of front bumper	Horn	*1
C210	1-BLK	Behind middle of front bumper	Horn (low)	*2
C211	2-GRY	Under hood latch	Hood switch	
C212	2-GRY	Behind middle of front bumper	Outside air temperature sensor	
C213	2-GRY	Right side of engine compartment	Security horn	*2
C214	8-GRY	Right side of engine compartment	Spark plug voltage detection module connector A	
C215	2-ORN	Right side of engine compartment	Right front wheel sensor	
C216	3-BLK	Behind right side of front bumper	Right fog light	*2
C217	1-BLK	Right side of engine compartment	Horn (high)	*2
G201		Right side of engine compartment	Body ground, via right engine compartment wire harness	
G202		Right side of engine compartment	Body ground, via right engine compartment wire harness	

*1: '96-'98

*2: '99-'04





Connector to Harness Index

