



Connector to Harness Index

Front Passenger's Door Wire Harness

Connector or Terminal	Cavities/Color	Location	Connects to	Notes
C445	42-GRY	Front passenger's door	Main wire harness	
C762	2-GRY	Front passenger's door	Front passenger's door speaker	
C763	2-GRY	Front passenger's door	Front passenger's power window motor	
C764	8-GRY	Front passenger's door	Front passenger's door latch	
C765	3-GRY	Front passenger's door	Front passenger's door key cylinder switch	
C766	2-GRY	Front passenger's door	Right tweeter	*3
C767	3-GRY	Front passenger's door	Front passenger's door lock switch	
C768	10-GRY	Front passenger's door	Right power mirror actuator	*5
C768	8-GRY	Front passenger's door	Right power mirror actuator	*6
C769	6-GRY	Front passenger's door	Power window switch	*1
C769	8-GRY	Front passenger's door	Power window switch	*2
C770	2-GRY	Front passenger's door	Front passenger's door courtesy light	
C771	2-GRY	Front passenger's door	Right tweeter	*4
C771	2-GRY	Front passenger's door	Right twiddler	*8
C772	12-GRY	Front passenger's door	Power mirror control unit	*7
C773	16-GRY	Front passenger's door	Power mirror control unit	*7

*1: '96-'97

*2: '98-'04

*3: Except BOSE sound system

*4: BOSE sound system

*5: Position memory

*6: Except position memory

*7: '02-'04

*8: '04

