



Connector to Harness Index

SRS Main Harness ('99-'04)

Connector or Terminal	Cavities/ Color	Location	Connects to	Notes
C475	8-YEL	Behind audio unit	Main wire harness	
C801	2-YEL	Behind left kick panel	Under-dash fuse/relay box	
C803	2-YEL	Under left side of dash	Memory erase signal (MES) connector	
C804	2-YEL	Under left side of dash	Cable reel	
C806	18-YEL	Behind audio unit	SRS unit connector A	
C807	4-YEL	Behind glove box	Front passenger's airbag assembly	
G801		Below front of console panel	Body ground, via SRS main harness	


SRS Floor Harness ('99-'04)

Connector or Terminal	Cavities/ Color	Location	Connects to	Notes
C616	2-YEL	Under passenger's seat	Right side wire harness	
C671	2-GRY	Under driver's seat	Left side wire harness	
C672	2-YEL	Under driver's seat	Left side wire harness	
C851	18-YEL	Behind audio unit	SRS unit connector B	
C854	4-YEL	Left side of floor	Driver's side impact sensor	
C855	2-YEL	Under driver's seat	Driver's side airbag assembly	
C856	2-YEL	Under passenger's seat	Front passenger's side airbag assembly	
C857	4-YEL	Right side of floor	Passenger's side impact sensor	

Right Side Wire Harness ('99-'04)

Connector or Terminal	Cavities/ Color	Location	Connects to	Notes
C614	4-GRY	Under front passenger's seat	OPDS unit connector D	





Connector to Harness Index

