



Circuit Index

- Accessory power socket 155
- Air conditioner – See HVAC
- Anti-lock brake system (ABS)
 - '96-'97 44
 - '98-'99 44
 - '00-'04 - See VSA
- A/T gear position indicator 89
- Automatic dimming mirror
 - '99-'01, '02-'04 Canada and '04 USA 142
 - '02-'03 USA 142
- Automatic transmission controls 39
- Back-up lights 110
- Brake lights
 - '96-'98 110
 - '99-'04 110
- Brake system indicator light
 - '96-'99 Canada 71
 - '96-'99 USA 71
 - '00-'04 71
- Ceiling lights
 - '96-'98 115
 - '99-'03 115
 - '04 115
- Charging system 22
- Cigarette lighter 155
- Clock 154
- Condenser fan 63
- Console lights – See Dash Lights
- Cornering lights
 - '96-'98 110
- Cruise control
 - '96-'98 34
 - '99-'04 34
- Dash lights
 - '96-'98 114
 - '99-'04 114
- Daytime running lights – See Headlights
- Door courtesy lights 115
- Driving position memory system (DPMS) 143
- Engine coolant temperature gauge
 - See Gauge Assembly
- Engine oil pressure indicator light
 - '96 72
 - '97-'03 72
 - '04 72
- Entry light control system 115
- Fans 63
- Fog lights
 - Canada 110
 - '96-'98 USA 110
 - '99-'04 USA 110
- Front parking/side marker lights
 - '96-'98 110
 - '99-'04 110
- Fuel gauge – See Gauge Assembly
- Fuse box
 - Under-dash 6
 - Under-hood 6
- Gauge assembly
 - '96-'97 80
 - '98-'03 80
 - '04 80
- Ground distribution index
- Ground-to-components index 6
- Hazard warning lights
 - '96-'98 110
 - '99-'04 110
 - except '04 Navi 110
 - '04 Navi 110
- Headlights
 - '96-'98 Canada 110
 - '96-'98 USA 110
 - '99 Canada 110
 - '99-'04 USA 110
 - '00-'04 Canada 110
- Headlight switch
 - '96-'98 Canada 100
 - '96-'98 USA 100
 - '99 Canada 100
 - '99-'04 USA 100
 - '00-'04 Canada 100
- Heater – See HVAC
- HomeLink® remote control system 157
- Horns
 - '96-'97 40
 - '98 40
 - '99-'04 40
- HVAC
 - Climate control 60
- Ignition key reminder 73
- Ignition system 20
- Immobilizer system
 - '96-'98 132
 - '99-'04 132
- Interlock system 138
- License lights
 - '96-'98 110
 - '99-'04 110
- Lights-on reminder 73
- Low fuel indicator light
 - '96-'03 74
 - '04 74
- Moonroof 122
- Multiplex control system 50
- Navigation system
 - '96-'99 156
 - '00-'03 156
 - '04 156
- Odometer – See Gauge Assembly
- OnStar® system
 - '02-'04 USA 159
- Power distribution
 - Battery to ignition switch, fuses, and relays 10
 - Fuses to relays and components 10
- Power door locks 130
- Power mirror defoggers 148
- Power mirrors 143
- Power seats
 - Front passenger's seat 140
 - Lumbar support 140
- Power windows
 - '96-'97 120
 - '98 120
 - '99-'01 120
 - '02-'04 120
- Programmed fuel injection system (PGM-FI) 23
- Radiator fan 63
- Rear side marker lights
 - '96-'98 110
- Rear window defogger
 - except '99-'04 Navigation 64
 - '99-'04 Navigation 64
- Safety indicator
 - '96-'03 84
 - '04 84
- Seat belt reminder 73
- Seat belt tension reducer
 - Driver's 145
 - Front passenger's 145
- Seat heater
 - '96-'97 147
 - '98 147
 - '99-'04 147
- Security system
 - '96-'98 Canada 133
 - '96-'98 USA 133
 - All '99-'04 133
- Speedometer – See Gauge Assembly
- Starting system 21
- Stereo sound system
 - Standard sound system ('96-'98) 150
 - Bose sound system
 - '96 150
 - '97-'03 150
 - '04 150
- Supplemental restraint system (SRS)
 - '96-'98 47
 - '99-'04 47
- Tachometer – See Gauge Assembly
- Taillights
 - '96-'98 110
 - '99-'04 110
- Traction control system (TCS) ('96-'99) 35
- Trailer lighting connector 118
- Trunk light 114
- Trunk opener 134
- Turn signal lights
 - except '04 Navi 110
 - '04 Navi 110
- Vanity mirror lights
 - '96-'98 114
 - '99-'03 115
 - '04 115
- Vehicle speed sensor (VSS) 33
- Vehicle stability assist (VSA) system ('00-'04) 36
- Wiper/washer
 - '96-'98 91
 - '99-'04 91

