

Land Rover Discovery 2018 fuse box diagram

Engine compartment fuse box

Fuse number	Ampere rating [A]	Circuit protected
1	—	—
2	—	—
3	—	—
4	—	—
5	—	—
6	—	—
7	—	—
8	—	—
9	25	Rear window washer
10	15	Front fog lights
11	15	Horn
12	30	Right-side headlight washer pump

13	30	Left-side headlight washer pump
14	15	Auto stop/start
15	15	Supercharger cooling
16	25	Windshield washer jets
17	10	Engine management system
18	20	Engine management system (gasoline only)
19	15	Engine management system
20	25	Engine management system
21	20	Engine management system
22	10	Engine management system (diesel only). Engine cooling fan (gasoline only)
23	10	Engine management system
24	15	Engine management system
25	10	Engine management system (diesel only)
26	—	—
27	—	—

28	—	—
29	5	Engine management system. Starter motor. Electrical power management
30	10	Heated wiper park
31	—	—
32	10	Steering wheel
33	5	Transfer case
34	5	Right-side Adaptive Front lighting System (AFS)
35	5	Headlight levelling
36	5	Left-side Adaptive Front lighting System (AFS)
37	—	—
38	—	—
39	—	—
40	15	Transmission. Terrain response switch. Gear selector
41	—	—
42	25	Left-side headlight

43	—	—
44	25	Right-side headlight
45	—	—
46	—	—
47	—	—
48	—	—
49	5	Engine management system
50	—	—
51	10	Engine management system
52	—	—
53	—	—
54	—	—
55	—	—
56	—	—
57	—	—

58	—	—
59	—	—
60	5	Heated wiper park

Passenger compartment fuse box

Fuse number	Ampere rating [A]	Circuit protected
1	20	Front cigar lighter
2	20	Front accessory socket. Rear accessory socket
3	20	Rear accessory socket
4	20	Rear accessory socket. USB sockets
5	—	—
6	—	—
7	5	Battery back-up sounder
8	—	—
9	—	—
10	20	Accessory sockets

11	30	Right-side rear seats
12	20	Panoramic roof
13	20	Panoramic roof
14	5	All Terrain Progress Control (ATPC)
15	—	—
16	—	—
17	—	—
18	30	Left-side rear seat
19	—	—
20	25	Left-side rear door
21	10	Cool box
22	—	—
23	20	Front passenger's seat. Left-side rear seat
24	25	Driver's door switches. Driver's door soft-close
25	15	Dynamic Stability Control (DSC)

26	10	Passenger seat switches
27	5	Tire Pressure Monitoring System (TPMS). Front overhead console
28	20	Driver's seat
29	25	Right-side rear door switches
30	20	Panoramic roof
31	—	—
32	—	—
33	30	Driver's seat
34	25	Passenger door switches. Passenger door soft-close
35	5	Brake pedal switch
36	—	—
37	—	—
38	—	—
39	—	—
40	—	—

41	5	Telematics
42	—	—
43	10	Heated steering wheel
44	10	Steering wheel
45	5	Touch screen buttons. Rear climate control
46	15	Climate control
47	—	—
48	—	—
49	5	Vehicle immobilizer
50	—	—
51	—	—
52	5	Air ionizer
53	—	—
54	5	Diagnostic socket
55	—	—

56	10	Climate control
----	----	-----------------

Loadspace fuse box

Fuse number	Ampere rating [A]	Circuit protected
1	—	—
2	25	Third row heated seats
3	15	Third row heated seats
4	—	—
5	—	—
6	—	—
7	5	Electrical power management
8	20	Driver's heated seat
9	15	Driver's seat switches. Front passenger's seat switches
10	20	Front passenger's heated seat
11	20	Right-side rear heated seat
12	—	—

13	20	Left-side rear heated seat
14	20	Rear wiper
15	30	Fuel system
16	15	Trailer socket
17	10	Diesel Exhaust Fluid (DEF)
18	20	Loadspace accessory power socket. Third row USB socket
19	20	Rear cigar lighter
20	20	Cubby box accessory socket
21	20	Loadspace accessory socket
22	—	—
23	—	—
24	10	Instrument panel
25	5	Air suspension
26	—	—
27	10	Parking aid. Rear-view mirror. Cameras. Blind spot assist

28	10	Head-Up Display (HUD)
29	5	Adaptive cruise control
30	30	Heated rear window. RF filter
31	—	—
32	—	—
33	15	Rear wiper
34	—	—
35	—	—
36	—	—
37	20	Driver's seat
38	—	—
39	30	Deployable side steps
40	—	—
41	—	—
42	20	Right-side rear seat

43	20	Keyless locking
44	15	Trailer socket
45	15	Engine management system. Fuel system
46	30	Fuel system
47	—	—
48	—	—
49	10	Gesture tailgate
50	15	Entertainment and information systems
51	15	Entertainment and information systems
52	10	Portable media
53	10	Portable media
54	5	Occupant sensor
55	15	Air suspension
56	10	Air suspension
57	5	Keyless locking

58	30	Front passenger's seat. Left-side rear seat
59	5	Rear-view camera
60	—	—