


Lincoln Mark VIII 1993 – 1995 fuse box diagram

Interior fuse box panel

Fuse panel is located on the lower left side of the instrument panel, near the driver side door.



Lincoln Mark VIII – fuse box – instrument

panel


Fuse	Ampere rating [A]	Functions
1	30	Blower Motor
2	8.25 (Circuit Breaker)	Wiper/Washer (1993)
3	30	Wiper/Washer (1994)
4	25	Parking Lights
5	10	Rear Defrost, EATC, Brake Shift Interlock, Traction Control Switch

6	15	Courtesy Lights, Power Mirrors, Dome Switch, Remote Keyless Entry (1993), , Electronic Door Lock Control (1994), Memory Seats
7	10	Power Antenna, Anti-Theft Relay, Memory Seats
8	20	Cigarette Lighter
9	10	Transmission Control Switch, Autolight Sensor, Electrochromic Mirrors
10	15	Suspension/Steering Module, Electronic Flasher, Steering Wheel Position Sensor, Daytime Running Lights, Back-Up Lights, Air Bag (1993), Air Bag Diagnostic Monitor (1994)
11	10	Stoplights, Hazard Lights, Brake Pressure Switch
12	20 (Circuit Breaker)	Power Seats, Fuel Door Release, Deck Lid Release, Shock Damping Control
13	10	Heated Mirrors, Compass
14	20 (Circuit Breaker)	Moon Roof, Power Windows, One-Touch Down Module
15	10	Warning Light Bank, Instrument Cluster, Chime Module, Charge Light
16	10	Air Bag, Power Antenna, EATC, Warning Light Bank, CD Changer, Radio, Message Center
17	15	Anti-Theft System, Cellular Phone, Chime, Compass, Memory Seats, Message Center, Power Antenna, Radio, Remote Keyless Entry (1993), Electronic Door Lock Control (1994)

18	10	Chime, Front Parking Lights, Front Side Marker Lights, Instrument Panel Light Dimmer, Rear Parking Lights, Power Mirror Dimmer Control
----	----	--

Underhood Fuse Panel

The high-current fuse panel is located in the engine compartment on the left hand fender apron.



Lincoln Mark VIII – fuse box – engine

compartment

Fuse	Ampere rating [A]	Functions
1	25	Daytime Running Lights (Canada), Horn
2	—	Blank
3	20	Alternator
4	15	Air Suspension Control Module

5	10	Speed Control
6	—	Blank
7	—	Blank
8	20	PCM/CCRM (1993), PCM/VCRM (1994)
9	30	Anti-Lock Brake System
10	50	Ignition Switch Feeds: Ignition Switch: B2, B3, B5; Instrument Panel Fuses: 1, 10, 15, 17; Maxi Fuse: 22; PDF: 5; Instrument Panel C/B: 2, 14
11	—	Blank
12	ABS Diode	Anti-Lock Brake System
13	40	Anti-Lock Brake Pump Motor
14	40	Headlamps
15	40	Rear Defrost
16	40	Engine Cooling Fan Control
17	50	Fuse Panel Feed: Instrument Panel Fuses: 4, 8, 16; Instrument Panel C/B: 12
18	40	Ignition Switch Feeds: Ignition Switch: B1, B4, Instrument Panel Fuses: 2, 5, 9, 14, 17
19	40	Fuse Panel Feed: Instrument Panel Fuses: 6, 11

20	50	Air Suspension Compressor
21	20	Premium Sound, Cellular Phone
22	20	EDIS/CCRM (1993) Electronic Ignition/VCRM (1994)
23	Relay	Fuel Pump
24	Relay	Anti-Lock Brake Control Module
25	Relay	Horn
26	Relay	High/Low Autolights
27	Relay	Parking Lights, Autolights