


GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

1. General Description

A: COMPONENT

1. FRONT BUMPER




- | | |
|-----------------|---------------------------|
| (1) Bumper face | (5) Side bracket |
| (2) E/A form | (6) Cover (Tie down hook) |
| (3) Bumper beam | (7) Cover |
| (4) Side stay | |

Tightening torque: N·m (kgf-m, ft-lb)
T: 33 (3.4, 25)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

2. REAR BUMPER (SEDAN)



- (1) Bumper beam
- (2) Upper beam
- (3) Resin beam
- (4) Side bracket


- (5) Bumper face
- (6) Hook
- (7) Side stay

Tightening torque: N·m (kgf-m, ft-lb)
T: 95 (9.7, 70)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

3. REAR BUMPER (WAGON)



- (1) Bumper beam
- (2) Resin beam
- (3) Side bracket


- (4) Bumper face
- (5) Hook
- (6) Side stay

Tightening torque: N·m (kgf-m, ft-lb)
T: 95 (9.7, 70)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

4. SIDE PROTECTOR



- (1) Side protector (Front fender)
- (2) Side protector (Front door)
- (3) Side protector (Rear door)


- (4) Side protector (Rear quarter)
- (5) Side garnish (Front fender)
- (6) Side garnish (Front door)

- (7) Side garnish (Rear door)
- (8) Side garnish (Rear quarter)
- (9) Side garnish (Side sill)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

5. DOOR TRIM




EI-00120

- | | | |
|------------------------|-------------------------------|-----------------|
| (1) Gusset cover | (5) Pad | (9) Upper trim |
| (2) Bracket | (6) Trim panel | (10) Side trim |
| (3) Weatherstrip upper | (7) Power window switch cover | (11) Lower trim |
| (4) Clip | (8) Weatherstrip lower | |

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

6. INNER TRIM (SEDAN)



EI-00121

- (1) Front pillar upper trim
- (2) Center pillar upper trim
- (3) Rear pillar upper trim
- (4) Rear shelf trim
- (5) Rear bulk trim


- (6) Trunk rear trim
- (7) Trunk side trim
- (8) Rear pillar lower trim
- (9) Side sill rear upper cover
- (10) Center pillar lower trim

- (11) Side sill rear lower cover
- (12) Front pillar lower trim
- (13) Side sill front lower cover
- (14) Pad stopper A pillar
- (15) Pad B pillar upper

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

7. INNER TRIM (WAGON)




EI-00122

- | | | |
|------------------------------|---------------------------------|----------------------------------|
| (1) Front pillar upper trim | (7) Lid | (13) Front pillar lower trim |
| (2) Center pillar upper trim | (8) Rear skirt trim | (14) Side sill front lower cover |
| (3) Rear pillar upper trim | (9) Hook | (15) Pad stopper A pillar |
| (4) Rear rail trim | (10) Side sill rear upper cover | (16) Pad B pillar upper |
| (5) Pocket | (11) Center pillar lower trim | |
| (6) Rear quarter lower trim | (12) Side sill rear lower cover | |

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

8. INSTRUMENT PANEL



EI-00123


- | | | |
|---------------------------|-----------------------|----------------------|
| (1) Pad & frame | (11) Front cover (MT) | (21) Switch panel |
| (2) Grille side (D) | (12) Rear cup holder | (22) Meter visor |
| (3) Hook | (13) Console box | (23) Grille vent (D) |
| (4) Grille side (P) | (14) Cap | (24) Grille center |
| (5) Grille vent (P) | (15) Console lid | |
| (6) Glove box panel | (16) Console cover | |
| (7) Glove box lid | (17) Tray | |
| (8) Center panel side (D) | (18) Ash tray | |
| (9) Center panel side (P) | (19) Lower cover | |
| (10) Front cover (AT) | (20) Center panel | |

Tightening torque: N·m (kgf-m, ft-lb)
T: 7 (0.7, 5.1)

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

9. INNER ACCESSORIES



- (1) Hook
- (2) Sun visor

- (3) Pad side rail
- (4) Assist grip

EI-00124

GENERAL DESCRIPTION

EXTERIOR/INTERIOR TRIM

B: PREPARATION TOOL

TOOL NAME	REMARKS
Clip remover	Used for removal of trim.
Adhesive remover	Used for removal of side protector.
Primer	Used for installation of side protector.
Infrared lamp	Used for disassembly/assembly of side protector.
Tow-sided tape	Used for installation of side protector.
TORX® T30	Used for disassembly/assembly of crossbar.