


Lincoln MKT 2010 – 2012 fuse box diagram

Passenger compartment fuse panel



Lincoln MKT – fuse box – passenger compartment


No.	A	Protected Components
1	30	Right rear smart window
2	15	Refrigerator
3	15	Driver seat switch, 2nd row lumbar switches
4	30	Right front smart window
5	10	Brake transmission shift interlock, 3rd row power fold module
6	20	Turn signals
7	10	Low beam headlamps (left)

8	10	Low beam headlamps (right)
9	15	Interior lights, Cargo lamps
10	15	Backlighting, Puddle lamps
11	10	All wheel drive (AWD)
12	7.5	Intelligent access (IA)
13	5	IA receiver, Exterior mirror switch, Steering column position switch, Driver seat module, Driver door module, Keypad
14	10	Power liftgate module, SYNC®, Rear entertainment
15	10	Climate control, Electronic finish panel
16	15	Navigation display, ALM, Auxiliary climate control
17	20	Global window open
18	20	Amplifier
19	25	Amplifier
20	15	Data link connector (OBD-2), 2nd row power fold seat motors
21	15	Fog lamps
22	15	Park lamps, License plate lamps, Illuminated liftgate applique

23	15	High beam headlamps, Auto high beam relay, Fog lamp deactivation relay
24	20	Horn
25	10	Demand lamps/interior lamps, 2nd row power fold seats, Powertrain control module (GTDI) wake-up, 3rd row seat relay
26	10	Instrument panel cluster, Heads up display
27	20	Ignition Switch, IA
28	5	Radio mute
29	5	Instrument panel cluster
30	5	Transmission shifter
31	10	Steering angle sensor, Heads up display
32	10	Restraint control module
33	10	Adaptive lighting module
34	5	Front body run/start feeds
35	10	Body module run/start feeds
36	5	Not used (spare)

37	10	Powertrain control module run/start, Fuel relay
38	20	Trailer tow park lamps
39	20	Audio control module
40	20	Cigarette lighter
41	15	Delayed accessory feeds
42	10	Not used (spare)
43	10	Auxiliary blower, Rear wiper, Rain sensor
44	10	Trailer tow backup lamps
45	5	Front wiper, Front blower, Wiper relay
46	7.5	Occupant classification sensor (OCS), Passenger airbag deactivation indicator (PADI), Front control interface module
47	30	Circuit Breaker: Not used
Relay		
48	Delayed accessory	

Engine Compartment Fuse Box



Lincoln MKT – fuse box diagram – engine

compartment

No.	A	Protected Components
1	–	Not used
2	–	Not used
3	30	Trailer tow brake controller
4	40	Wiper relay (front and rear)
5	30	Passenger power seat
6	30	110V AC inverter
7	30	Rear climate control seat module
8	30	Front climate control seat module
9	40	Anti-lock brake system (ABS) pump
10	30	Starter
11	30	Powertrain control module (PCM) vehicle power

12	20	ABS valve
13	20	Right high intensity discharge (HID) headlamp
14	10	Brake on/off (BOO) switch, Adaptive cruise relay
15	15	Automatic high beams, Adaptive cruise control
16	20	Left HID headlamp
17	10	Alternator sensor
18	30	3rd row power seats
19	20	Front console power point
20	40	Rear defroster, Heated mirrors
21	20	Rear console power point
22	40	Trailer tow battery charge, Trailer tow stop/turn lamps fuse 45 power
23	10	PCM keep alive power, Canister vent, Relay coil
24	10	A/C clutch
25	20	Rear power point
26	15	Backup lamps

27	15	Fuel relay (Fuel pump driver module, Fuel pump)
28	80	Cooling fan
29	30	Left rear smart window, Panoramic roof module, Power sunshade module
30	30	Left front smart window
31	40	Auxiliary blower motor
32	30	Driver seat motor, Memory motor power
33	30	Run/start relay
34	30	Power liftgate
35	40	Front A/C blower
36	25	Rear wiper module (secondary fuse)
37	15	Washer pump
38	10	Trailer tow backup lamps
45	20	Trailer tow stop/turn lamps (secondary fuse)
46	15	PCM vehicle power 2, Vehicle power 3
47	20	PCM vehicle power 1

48	15	PCM vehicle power 4 (coil on plugs)
49	10	Heated mirrors (secondary fuse)
Diode		
39	Fuel pump motor diode	
40	One touch integrated start diode	
Relay		
41	Trailer tow park lamp	
42	Trailer tow stop/turn lamp (left)	
43	Trailer tow stop/turn lamp (right)	
44	Backup lamps relay	
50	Blower motor	
51	Fog lamp deactivation	
52	Starter	
53	Adaptive cruise control	
54	3rd row power seats	

55	Wipers (front)
56	Rear window defroster, Heated mirrors
57	Not used
58	Not used
59	Auxiliary blower motor
60	Trailer tow battery charge
61	Refrigerator
62	Automatic high beams
63	Run/start
64	PCM
65	A/C clutch
66	Fuel pump