HOW TO PROCEED WITH TROUBLESHOOTING

1 **VEHICLE BROUGHT TO WORKSHOP**

NEXT

2 **CUSTOMER PROBLEM ANALYSIS (See page IN-26)**

NEXT

3 **PASSENGER AIRBAG ON/OFF INDICATOR CHECK (See page RS-484)**

NEXT

4 **DTCs CHECK (Present and Past DTCs) (See page RS-487)**

(a) Check for DTCs.
Result

Result	Proceed to
DTC is output.	A
DTC is not output.	B

B → **GO TO PROBLEM SYMPTOMS TABLE**

A

5 **DTCs CHART (See page RS-489)**

NEXT

6 **CIRCUIT INSPECTION**

NEXT

7 **REPAIR OR REPLACEMENT**

NEXT

8 **DTC CLEARANCE (Present and Past DTCs) (See page RS-487)**

(a) Clear the DTCs.

cardiagn.com

NEXT

9	DTC CHECK (Present and Past DTCs) (See page RS-487)

(a) Check for DTCs.
Result

Result	Proceed to
DTC is not output.	A
DTC is output.	B

B → **Go to step 5**

A

10	SYMPTOM SIMULATION

(a) Check the passenger airbag ON/OFF indicator condition (See page RS-484).

Result

Result	Proceed to
Passenger airbag ON/OFF indicator is operating normally.	A
Passenger airbag ON/OFF indicator (OFF) and SRS warning light come on.	B

B → **Go to step 5**

A

11	CONFIRMATION TEST

NEXT

END

RS

cardiagn.com