Fiat 500cc (2012 – 2014) fuse box diagram (USA version)

Interior fuses

The interior fuse panel is part of the Body Control Module (BCM) and is located on the drivers's side under the instrument panel.

Cavity	Vegicle fuse number	Mini fuse (ampere fuse)	Colour	Description
1	F12	7,5	Brown	Right Low Beam
2	F32	5	Tan	Front and Rear Ceiling Lights Trunk and Door Courtesy Lights
3	F53	5	Tan	Instrument Panel Node
4	F38	20	Yellow	Central Door Locking
5	F36	10	Red	Diagnostic Socket, Car Radio, Climate Control System
6	F43	20	Yellow	Bi-Directional Washer
7	F48	20	Yellow	Passenger Power Window
8	F13	7,5	Brown	Left Low Beam, Headlamp Leveling
9	F50	7,5	Brown	Airbag
10	F51	5	Tan	Car Radio Switch, Climate Control System, Stop Light, Clutch
11	F37	5	Tan	Stop Light Switch, Instrument Panel Node
12	F49	5	Tan	Exterior Mirror, GPS, Electric Mirror, Parking Sensor
13	F47	20	Yellow	Driver Power Window

Underhood fuses

The front distribution units is located on the right side of engine compartment, next to the battery.

Cavity	Maxi fuse	Mini fuse	Description
F01	60A (Blue)		Body Controller
F02	20A (Yellow)		Audio Amplifier
F03	20A (Yellow)		Ignition Switch
F04	40A (Orange)		Anti-Lock Brake Pump
F05	70A (Tan)		Electric Power Steering
F06	20 (Yellow)		Radiator Fan – Single Speed
F07	40A (Orange)		Radiator Fan – High Speed
F08	30A (Green)		Blower Motor
F09		10A (Red)	Powertrain

F10		10A (Red)	Horn
F11		15A (Blue)	Powertrain
F11		10A (Red)	Powertrain (Multiair – If Equipped)
F14		5 (Tan)	High beam (Shutter)
F15		15A (Blue)	Cigar Lighter
F16		7,5 (Brown)	Transmission
F17		25A (White)	Powertrain (Multiair – If Equipped)
F17		15A (Blue)	Powertrain
F18		15A (Blue)	Powertrain
F18		5 (Tan)	Powertrain (Multiair – If Equipped)
F19		7,5 (Brown)	Air Conditioning
F20		15A (Blue)	Heated Seats – If Equipped
F21		15A (Blue)	Fuel Pump
F23		20A (Yellow)	Anti-Lock Brake Valves
F24		7,5A (Brown)	Stability Control System
F30		15A (Blue)	Fog Lamps
F82	30A (Green)		Sunroof/ Convertible Top
F84		10A (Red)	Transmission
F85		15A (Blue)	Rear Defroster, Heated Mirrors
F87		5A (Tan)	Lights
F90		5A (Tan)	Heated Mirrors

The ID number of the electrical component corresponding to each fuse can be found on the back of the cover.