2000 Dodge Intrepid Alarm, Remote Start, Keyless Entry Wiring Information		
Constant 12V+	Pink/Black or Red	Ignition Switch Harness
Starter	Yellow	Ignition Switch Harness
Ignition	Dark Blue/White	Ignition Switch Harness
Ignition 2	Green/Red	Ignition Switch Harness (Air Bag Light)
Accessory	Black/White	Ignition Switch Harness
Tach	Tan/White	Any Coil, Use 1 Cylinder Setting
Neutral Safety Wire	Tan/White (-)	Power Control Module PCM see notes
Brake Switch	White/Tan	Brake Switch
Trunk Release	Black/White (+)	Switch
Trunk Pin	Tan/Black (-)	Black 22 Pin Connector Driver's Kick Panel
Parking Lights	Black/Yellow (+)	Driver's Kick Panel
Head Lamp	Purple (+)	Or Purple/Red Fuse Panel Driver's Kick Panel
Factory Disarm	Light Green/Orange (+)	Driver's Kick Panel
Door Trigger	Yellow (-)	Brown Connector at Rear of Fuse Panel
Door Lock	White/Dark Green (+)	22 Pin Connector Driver's Kick Panel 2.7K Ohm Lock
Door Unlock	White/Dark Green (+)	620 Ohm Unlock One Wire see notes
Driver's Lock	Orange	BCM
Driver's Unlock	Dark Blue	BCM
Passenger Unlock	Pink/Black	BCM
Horn Wire	Black/Red (-)	Horn Relay in Fuse Panel
Windows Up	LF=Light Blue/Gold, RF=Brown/White, LR=Blue/White, RR=Gray/Black	
Windows Down	LF=White/Gold, RF=Purple/White, LR=Red/Blue, RR=Green/White	