DIAGNOSTIC TROUBLE CODE CHART

COMMUNICATION DIAGNOSIS

DTC No.	Detection Item	Trouble Area	See page
01-21	ROM Error	Radio receiver	AV-26
01-22	RAM Error	Radio receiver	AV-26
01-D5	Absence of Registration Unit	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-27
01-D6	No Master	1. Radio receiver power source circuit 2. Power source circuit of the component which has stored this code 3. AVC-LAN circuit between the radio receiver and the component which has stored this code 4. Component which has stored this code 5. Radio receiver	AV-29
01-D7	Connection Check Error	1. Radio receiver power source circuit 2. Power source circuit of the component which has stored this code 3. AVC-LAN circuit between the radio receiver and the component which has stored this code 4. Component which has stored this code 5. Radio receiver	AV-29
01-D8	No Response for Connection Check	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-27
01-D9	Last Mode Error	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-27
01-DA	No Response Against ON / OFF Command	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-27

DTC No.	Detection Item	Trouble Area	See page
01-DB	Mode Status Error	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-27
01-DC	Transmission Error	If the same sub-code is recorded in other components, check harness for power supply and communication system of all components shown by code	AV-33
01-DD	Master Reset	1. Radio receiver power source circuit 2. AVC-LAN circuit between the radio receiver and the component which has stored this code 3. Radio receiver 4. Component which has stored this code	AV-36
01-DE	Slave Reset	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-27
01-DF	Master Error	1. Radio receiver power source circuit 2. AVC-LAN circuit between the radio receiver and the component which has stored this code 3. Radio receiver 4. Component which has stored this code	AV-40
01-E0	Registration Complete Indication Error	-	AV-44
01-E1	Voice Processing Device ON Error	1. Radio receiver power source circuit 2. AVC-LAN circuit between the radio receiver and the component which has stored this code 3. Radio receiver 4. Component which has stored this code	AV-36
01-E2	ON / OFF Indication Parameter Error	Radio receiver	AV-45
01-E3	Registration Demand Transmission	-	AV-44
01-E4	Multiple Frame Incomplete	-	AV-44

CD PLAYER

DTC No.	Detection Item	Trouble Area	See page
62-10	CD Player Mechanical Error	Radio receiver	AV-46
62-11	CD Insertion and Eject Error	Radio receiver	AV-46
62-12	CD Reading Abnormal	Radio receiver	AV-46
62-41	Wrong Disc	1. CD 2. Radio receiver	AV-47
62-42	Disc cannot be Read	1. CD 2. Radio receiver	AV-47

DTC No.	Detection Item	Trouble Area	See page
62-43	CD-ROM Abnormal	1. CD 2. Radio receiver	AV-49
62-44	CD Abnormal	Radio receiver	AV-50
62-45	Eject Error	Radio receiver	AV-51
62-46	Scratched / Reversed Disc	1. CD 2. Radio receiver	AV-52
62-47	High Temperature	Radio receiver	AV-54
62-48	Excess Current	Radio receiver	AV-50
62-50	Tray Insertion / Ejection Error	Radio receiver	AV-50
62-51	Elevator Error	Radio receiver	AV-51
62-52	Clamp Error	Radio receiver	AV-51

IN-DASH CD CHANGER

DTC No.	Detection Item	Trouble Area	See page
63-10	CD Changer Mechanical Error	Radio receiver	AV-46
63-11	CD Insertion and Eject Error	Radio receiver	AV-46
63-12	CD Reading Abnormal	Radio receiver	AV-46
63-41	Wrong Disc	1. CD 2. Radio receiver	AV-47
63-42	Disc cannot be Read	1. CD 2. Radio receiver	AV-47
63-43	CD-ROM Abnormal	1. CD 2. Radio receiver	AV-49
63-44	CD Abnormal	Radio receiver	AV-50
63-45	Eject Error	Radio receiver	AV-51
63-46	Scratched / Reversed Disc	1. CD 2. Radio receiver	AV-52
63-47	High Temperature	Radio receiver	AV-54
63-48	Excess Current	Radio receiver	AV-50
63-50	Tray Insertion / Ejection Error	Radio receiver	AV-50
63-51	Elevator Error	Radio receiver	AV-51
63-52	Clamp Error	Radio receiver	AV-51