

2000 Dodge Durango Alarm, Remote Start, Keyless Entry Wiring Information

Constant 12V+	Pink/Black or Red	Ignition Switch Harness
Starter	Yellow	Ignition Switch Harness
Ignition	Dark Blue (+)	Ignition Switch Harness
Ignition 2	Black/Orange	Ignition Switch Harness (Heat/AC)
Accessory	Black/White	Ignition Switch Harness
Tach	Black/Gray	Coil
Neutral Safety Wire	Yellow	Lower left of Dash 16 Pin Connector Position 3
Brake Switch	White/Tan	Brake Switch
Trunk Release	Tan/Black-Pink/Black	18 Pin Connector Position 15 Module right of Glove
Trunk Pin	Tan/Black (-)	16 Pin Connector below Fuse Panel
Parking Lights	Black/Yellow (+)	18 Pin Connector Position 1 Head Light Switch
Head Lamp	Light Green (+)	Light Switch
Factory Disarm	Light Green/Orange(-)	18 Pin Connector Driver's Kick Panel Position 10 Same Wire Arm
Door Trigger	Yellow (-)	Head Light Switch or Courtesy Light SEE NO
Door Lock	Orange/Purple (+)	18 Pin Connector Position 4 Module right of Dash
Door Unlock	Pink/Purple (+)	Position 13 (+) w/Keyless Reverse Polarity w/o Keyless
Driver's Lock	Orange/Black	Driver's Kick Panel
Driver's Unlock	Blue	Driver's Kick Panel
Passenger Unlock	Pink/Black	Driver's Kick Panel
Horn Wire	Black/Red (-)	Steering Column Harness
Windows Up	LF=Light Blue, RF=Brown/White, LR=Blue/White, RR=Gray/Black	
Windows Down	LF=White, RF=Purple/White, LR=Red/Black, RR=Green/White	